Operation Guide

UT35A/UT32A
Digital Indicating Controllers
Operation Guide

UTAdvanced

IM 05P01D31-11EN

Installation and Wiring

YOKOGAWA
Yokogawa Electric Corporation

3rd Edition : Jan. 2011

This operation guide describes installation, wiring, and other tasks required to make the controller ready for operation.

Contents

1. Safety Precautions
2. Model and Suffix Codes
3. How to Install
4. Hardware Specifications
5. How to Connect Wires
6. Terminal Wiring Diagrams

Introduction

Thank you for purchasing the UT35A/UT32A Digital Indicating Controller.
This operation guide describes the basic operations of the UT35A/UT32A. The guide should be provided to the end user of this product.
Be sure to read this operation guide before using the product in order to ensure correct operation.
For details of each function, refer to the electronic manual. Before using the product, refer to the table of Model and Suffix Codes to make sure that the delivered product is consistent with the model and suffix codes you ordered. Also make sure that the following items are included in the package.

- Digital Indicating Controller (the model you ordered).....x1
- Set of Brackets.....x1
- Unit Label (L4502VZ).....x1
- Tag Label (L4502VE).....x1

(Only when ordered.)

- Operation Guide (this document).....x6 (A3 size)
  (Installation and Wiring, Initial Settings, Operations, and Parameters)

● Target Readers
This guide is intended for the following personnel;
- Engineers responsible for installation, wiring, and maintenance of the equipment.
- Personnel responsible for normal daily operation of the equipment.

1. Safety Precautions

The following symbol is used on the instrument. It indicates the possibility of injury to the user or damage to the instrument, and signifies that the user must refer to the user's manual for special instructions. The same symbol is used in the user's manual on pages that the user needs to refer to, together with the term "WARNING" or "CAUTION."

WARNING

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and indicates precautions that should be taken to prevent such occurrences.

CAUTION

Calls attention to actions or conditions that could cause injury to the user or damage to the instrument or property and indicates precautions that should be taken to prevent such occurrences.

AC

AC/DC

The equipment wholly protected by double insulation or reinforced insulation.

Functional grounding terminals
(Do not use this terminal as a protective grounding terminal).

Note

Identifies important information required to operate the instrument.

■ Warning and Disclaimer

(1) YOKOGAWA makes no warranties regarding the product except those stated in the WARRANTY that is provided separately.
(2) The product is provided on an "as is" basis. YOKOGAWA assumes no liability to any person or entity for any loss or damage, direct or indirect, arising from the use of the product or from any unpredictable defect of the product.

■ Safety, Protection, and Modification of the Product

(1) In order to protect the system controlled by this product and the product itself, and to ensure safe operation, observe the safety precautions described in the user's manual. Use of the instrument in a manner not prescribed herein may compromise the product's functions and the protection features inherent in the device. We assume no liability for safety, or responsibility for the product's quality, performance or functionality should users fail to observe these instructions when operating the product.
(2) Installation of protection and/or safety circuits with respect to a lightning protector; protective equipment for the system controlled by the product and the product itself; foolproof or fail-safe design of a process or line using the system controlled by the product or the product itself; and/or the design and installation of other protective and safety circuits are to be appropriately implemented as the customer deems necessary.
(3) Be sure to use the spare parts approved by YOKOGAWA when replacing parts or consumables.
(4) This product is not designed or manufactured to be used in critical applications that directly affect or threaten human lives. Such applications include nuclear power equipment, devices using radioactivity, railway facilities, aviation equipment, air navigation facilities, aviation facilities, and medical equipment. If so used, it is the user's responsibility to include in the system additional equipment and devices that ensure personnel safety.
(5) Modification of the product is strictly prohibited.
(6) This product is intended to be handled by skilled/trained personnel for electric devices.
(7) This product is UL Recognized Component. In order to comply with UL standards, end-products are necessary to be designed by those who have knowledge of the requirements.

WARNING

- **Power Supply**
  Ensure that the instrument's supply voltage matches the voltage of the power supply before turning ON the power.
- **Do Not Use in an Explosive Atmosphere**
  Do not operate the instrument in locations with combustible or explosive gases or steam. Operation in such environments constitutes an extreme safety hazard. Use of the instrument in environments with high concentrations of corrosive gas (H_2S, SO_X, etc.) for extended periods of time may cause a failure.
- **Do Not Remove Internal Unit**
  The internal unit should not be removed by anyone other than YOKOGAWA's service personnel. There are dangerous high voltage parts inside. Additionally, do not replace the fuse by yourself.
- **Damage to the Protective Construction**
  Operation of the instrument in a manner not specified in the user's manual may damage its protective construction.

CAUTION

This instrument is an EMC class A product. In a domestic environment this product may cause radio interference in which case the user needs to take adequate measures.

2. Model and Suffix Codes

■ UT35A

[Style: S3]

Model	Suffix code							Optional suffix code	Description
UT35A									Digital Indicating Controller (provided with retransmission output or 15 V DC loop power supply, 2 DIs, and 3 DOs) (Power supply: 100-240 V AC)
Type 1: Basic control	-0								Standard type
	-1								Position proportional type
	-2								Heating/cooling type
Type 2: Functions		0							None
		1							2 additional DIs, 2 additional DOs
		2							5 additional DIs, 5 additional DOs
Type 3: Open networks			0						None
			1						RS-485 communication (Max.38.4 kbps, 2-wire/4-wire)
			2						Ethernet communication (with serial gateway function)
			3						CC-Link communication (with Modbus master function)
			4						PROFIBUS-DP communication (with Modbus master function)
			5						DeviceNet communication (with Modbus master function)
Display language (*1)				-1					English
				-2					German
				-3					French
				-4					Spanish
Case color					0				White (Light gray)
					1				Black (Light charcoal gray)
Fixed code						-00			Always "-00"
Optional suffix codes							/LP		24 V DC loop power supply (*2)
							/HA		Heater break alarm (*3)
							/DC		Power supply 24 V AC/DC
							/CT		Coating (*4)

*1: English, German, French, and Spanish can be displayed as the guide display.
*2: The /LP option can be specified in the combination of Type 2 code (any of "0" or "1") and Type 3 code (any of "0" or "1".)
*3: The /HA option can be specified when the Type 1 code is "-0" or "-2".
*4: When the /CT option is specified, the UT35A does not conform to the safety standards (UL and CSA) and CE marking.

■ UT32A

[Style: S3]

Model	Suffix code							Optional suffix code	Description
UT32A									Digital Indicating Controller (provided with retransmission output or 15 V DC loop power supply, 2 DIs, and 3 DOs) (Power supply: 100-240 V AC)
Type 1: Basic control	-0								Standard type
	-1								Position proportional type
	-2								Heating/cooling type
Type 2: Functions		0							None
		1							RS-485 communication (Max. 38.4 kbps, 2-wire/4-wire)
		2							2 additional DIs and 2 additional DOs
Type 3: Open networks			0						None
Display language (*1)				-1					English
				-2					German
				-3					French
				-4					Spanish
Case color					0				White (Light gray)
					1				Black (Light charcoal gray)
Fixed code						-00			Always "-00"
Optional suffix codes							/LP		24 V DC loop power supply (*2)
							/HA		Heater break alarm (*3)
							/DC		Power supply 24 V AC/DC
							/CT		Coating (*4)

*1: English, German, French, and Spanish can be displayed as the guide display.
*2: The /LP option can be specified in the combination of Type 1 code (any of "-0" or "-1") and Type 2 code (any of "0" or "1.") Additionally, when the Type 2 code is "1", the RS-485 communication is 2-wire system.
*3: The /HA option can be specified when the Type 1 code is "-0" or "-2."
*4: When the /CT option is specified, the UT32A does not conform to the safety standards (UL and CSA) and CE marking.

■ Accessories (sold separately)

The following is an accessory sold separately.

- LL50A Parameter Setting Software

Model	Suffix code	Description
LL50A	-00	Parameter Setting Software

- Terminal Cover
  For UT35A: Model UTAP001; For UT32A: Model UTAP002
- User's Manual (A4 size)
  Note: User's Manual can be downloaded from a website.
- User's Manual (CD-ROM), Model: UTAP003
  Note: Contains all manuals.
- Brackets
  Part number: L4502TP (2 pcs for upper and lower sides)

■ Waste Electrical and Electronic Equipment (WEEE), Directive 2002/96/EC

This is an explanation of how to dispose of this product based on Waste Electrical and Electronic Equipment (WEEE), Directive 2002/96/EC. This directive is only valid in the EU.

Marking

This product complies with the WEEE Directive (2002/96/EC) marking requirement.
This marking indicates that you must not discard this electrical/electronic product in domestic household waste.

Product Category

With reference to the equipment types in the WEEE directive Annex 1, this product is classified as a "Monitoring and Control instrumentation" product. Do not dispose in domestic household waste. When disposing products in the EU, contact your local Yokogawa Europe B.V. office.

3. How to Install

■ Installation Location

The instrument should be installed in indoor locations meeting the following conditions:

- **Instrumented panel**
  This instrument is designed to be mounted in an instrumented panel. Mount the instrument in a location where its terminals will not inadvertently be touched.
- **Well ventilated locations**
  Mount the instrument in well ventilated locations to prevent the instrument's internal temperature from rising.
  However, make sure that the terminal portions are not exposed to wind. Exposure to wind may cause the temperature sensor accuracy to deteriorate. To mount multiple indicating controllers, see the external dimensions/panel cutout dimensions which follow. If mounting other instruments adjacent to the instrument, comply with these panel cutout dimensions to provide sufficient clearance between the instruments.
- **Locations with little mechanical vibration**
  Install the instrument in a location subject to little mechanical vibration.
- **Horizontal location**
  Mount the instrument horizontally and ensure that it is level, with no inclination to the right or left.



Note

If the instrument is moved from a location with low temperature and low humidity to a place with high temperature and high humidity, or if the temperature changes rapidly, condensation will result. Moreover, in the case of thermocouple inputs, measurement errors will result. To avoid such a situation, leave the instrument in the new environment under ambient conditions for more than 1 hour prior to using it.

Do not mount the instrument in the following locations:

- **Outdoors**
- **Locations subject to direct sunlight or close to a heater**
  Install the instrument in a location with stable temperatures that remain close to an average temperature of 23°C. Do not mount it in locations subject to direct sunlight or close to a heater. Doing so adversely affects the instrument.
- **Locations with substantial amounts of oily fumes, steam, moisture, dust, or corrosive gases**
  The presence of oily fumes, steam, moisture, dust, or corrosive gases adversely affects the instrument. Do not mount the instrument in locations subject to any of these substances.
- **Areas near electromagnetic field generating sources**
  Do not place magnets or tools that generate magnetism near the instrument. If the instrument is used in locations close to a strong electromagnetic field generating source, the magnetic field may cause measurement errors.
- **Locations where the display is difficult to see**
  The instrument uses an LCD for the display unit, and this can be difficult to see from extremely oblique angles. Mount the instrument in a location where it can be seen as much as possible from the front.
- **Areas close to flammable articles**
  Absolutely do not place the instrument directly on flammable surfaces. If such a circumstance is unavoidable and the instrument must be placed close to a flammable item, provide a shield for it made of 1.43 mm thick plated steel or 1.6 mm thick unplated steel with a space of at least 150 mm between it and the instrument on the top, bottom, and sides.
- **Areas subject to being splashed with water**



WARNING

Be sure to turn OFF the power supply to the controller before installing it on the panel to avoid an electric shock.

YOKOGAWA
YOKOGAWA ELECTRIC CORPORATION
Network Solutions Business Division
2-9-32, Naka-cho Musashino-shi, Tokyo 180-8750 JAPAN
YOKOGAWA CORPORATION OF AMERICA
Head office and for product sales
2 Dart Road, Newnan, Georgia 30265, USA
YOKOGAWA EUROPE B.V.
Headquarters
Euroweg 2, 3825 HD Amersfoort, THE NETHERLANDS
www.yokogawa.com/ns

All Rights Reserved, Copyright © 2010 Yokogawa Electric Corporation

■ Mounting the Instrument Main Unit

Provide an instrumented panel steel sheet of 1 to 10 mm thickness.
After opening the mounting hole on the panel, follow the procedures below to install the controller:

1) Insert the controller into the opening from the front of the panel so that the terminal board on the rear is at the far side.
2) Set the brackets in place on the top and bottom of the controller as shown in the figure below, then tighten the screws of the brackets. Take care not to overtighten them.



CAUTION

- **Tighten the screws with appropriate tightening torque within 0.25 N•m. Otherwise it may cause the case deformation or the bracket damage.**
- **Make sure that foreign materials do not enter the inside of the instrument through the case's slit holes.**

■ External Dimensions and Panel Cutout Dimensions

UT35A

Unit: mm (approx. inch)



• General mounting



• Side-by-side close mounting



"N" stands for the number of controllers to be installed.
However, the measured value applies if N≥5.

Normal tolerance:
±(value of JIS B 0401-1998 tolerance class IT18)/2

UT32A

Unit: mm (approx. inch)



• General mounting



• Side-by-side close mounting



"N" stands for the number of controllers to be installed.
However, the measured value applies if N≥5.

Normal tolerance:
±(value of JIS B 0401-1998 tolerance class IT18)/2

4. Hardware Specifications

WARNING

This instrument is for Measurement Category I (CAT.I). Do not use it for measurements in locations falling under Measurement Categories II, III, and IV.



Category	Measurement category	Description	Remarks
I	CAT.I	For measurements performed on circuits not directly connected to MAINS.	-
II	CAT.II	For measurements performed on circuits directly connected to the low-voltage installation.	Appliances, portable equipment, etc.
III	CAT.III	For measurements performed in the building installation.	Distribution board, circuit breaker, etc.
IV	CAT.IV	For measurements performed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.

■ Input Specifications

●Universal Input (Equipped as standard)

- Number of inputs: 1
- Input type, instrument range, and measurement accuracy: See the table below,

Input Type		Instrument Range °C	Instrument Range °F	Accuracy
Thermocouple	K	-270.0 to 1370.0ºC	-450.0 to 2500.0ºF	±0.1% of instrument range ±1 digit for 0°C or more ±0.2% of instrument range ±1 digit for less than 0°C
		-270.0 to 1000.0ºC	-450.0 to 2300.0ºF	
		-200.0 to 500.0ºC	-200.0 to 1000.0ºF	
	J	-200.0 to 1200.0ºC	-300.0 to 2300.0ºF	±2% of instrument range ±1 digit for less than -200.0°C of thermocouple K ±1% of instrument range ±1 digit for less than -200.0°C of thermocouple T
	T	-270.0 to 400.0ºC	-450.0 to 750.0ºF	
		0.0 to 400.0ºC	-200.0 to 750.0ºF	
	B	0.0 to 1800.0ºC	32 to 3300ºF	±0.15% of instrument range ±1 digit for 400°C or more ±5% of instrument range ±1 digit for less than 400°C
	S	0.0 to 1700.0ºC	32 to 3100ºF	±0.15% of instrument range ±1 digit
	R	0.0 to 1700.0ºC	32 to 3100ºF	
	N	-200.0 to 1300.0ºC	-300.0 to 2400.0ºF	±0.1% of instrument range ±1 digit ±0.25% of instrument range ±1 digit for less than 0°C
	E	-270.0 to 1000.0ºC	-450.0 to 1800.0ºF	±0.1% of instrument range ±1 digit for 0°C or more ±0.2% of instrument range ±1 digit for less than 0°C
	L	-200.0 to 900.0ºC	-300.0 to 1600.0ºF	
	U	-200.0 to 400.0ºC	-300.0 to 750.0ºF	
		0.0 to 400.0ºC	-200.0 to 1000.0ºF	±1.5% of instrument range ±1 digit for less than -200.0°C of thermocouple E.
	W	0.0 to 2300.0ºC	32 to 4200ºF	±0.2% of instrument range ±1 digit (Note 2)
	Platinel 2	0.0 to 1390.0ºC	32.0 to 2500.0ºF	±0.1% of instrument range ±1 digit
	PR20-40	0.0 to 1900.0ºC	32 to 3400ºF	±0.5% of instrument range ±1 digit for 800°C or more Accuracy is not guaranteed for less than 800°C.
	W97Re3-W75Re25	0.0 to 2000.0ºC	32 to 3600ºF	±0.2% of instrument range ±1 digit
RTD	JPt100	-200.0 to 500.0ºC	-300.0 to 1000.0ºF	±0.1% of instrument range ±1 digit (Note 1)
		-150.00 to 150.00ºC	-200.0 to 300.0ºF	±0.1% of instrument range ±1 digit
	Pt100	-200.0 to 850.0ºC	-300.0 to 1560.0ºF	±0.1% of instrument range ±1 digit (Note 1)
		-200.0 to 500.0ºC	-300.0 to 1000.0ºF	
		-150.00 to 150.00ºC	-200.0 to 300.0ºF	±0.1% of instrument range ±1 digit
Standard signal		0.400 to 2.000 V		±0.1% of instrument range ±1 digit
		1.000 to 5.000 V		
		4.00 to 20.00 mA		
DC voltage/current		0.000 to 2.000 V		
		0.00 to 10.00 V		
		0.00 to 20.00 mA		
		-10.00 to 20.00 mV		
		0.0 to 100.0 mV		

The accuracy is that in the standard operating conditions: 23±2°C, 55±10%RH, and power frequency at 50/60 Hz.
Note 1: ±0.3°C ±1 digit in the range between 0 and 100°C, ±0.5°C ±1 digit in the range between -100 and 200°C.
Note 2: W: W-5% Re/W-26% Re(Hoskins Mfg.Co.). ASTM E988

- Input sampling (control) period: 200 ms
- Burnout detection:
  Functions at TC, RTD, and standard signal.
  Upscale, downscale, and off can be specified.
  For standard signal, burnout is determined to have occurred if it is 0.1 V or 0.4 mA or less.
- Input bias current: 0.05 μA (for TC or RTD)
- Measured current (RTD): About 0.16 mA
- Input resistance:
  TC or mV input: 1 MΩ or more
  V input: About 1 MΩ
  mA input: About 250 Ω
- Allowable signal source resistance:
  TC or mV input: 250 Ω or less
  Effects of signal source resistance: 0.1 μV/Ω or less
  DC voltage input: 2 kΩ or less
  Effects of signal source resistance: About 0.01%/100 Ω
- Allowable wiring resistance:
  RTD input: Max. 150 Ω/wire (The conductor resistance between the three wires shall be equal.)
  Wiring resistance effect: ±0.1ºC/10 Ω
- Allowable input voltage/current:
  TC, mV, mA and RTD input: ±10 V DC
  V input: ±20 V DC
  mA input: ±40 mA
- Noise rejection ratio:
  Normal mode: 40 dB or more (at 50/60 Hz)
  Common mode: 120 dB or more (at 50/60 Hz)
  For 100-240 V AC, the power frequency can be set manually. Automatic detection is also available.
  For 24 V AC/DC, the power frequency can be set manually.
- Reference junction compensation error:
  ±1.0ºC (15 to 35ºC)
  ±1.5ºC (-10 to 15ºC and 35 to 50ºC)
- Applicable standards: JIS/IEC/DIN (ITS-90) for TC and RTD

■ Analog Output Specifications

- Number of outputs:
  Control output: 1
  Cooling-side control output of Heating/cooling type (Retransmission output terminal): 1
- Output type: Current output or voltage pulse output
- Current output: 4 to 20 mA DC or 0 to 20 mA DC/load resistance of 600 Ω or less
- Current output accuracy: ±0.1% of span (±5% of span for 1 mA or less)
  The accuracy is that in the standard operating conditions: 23±2°C, 55±10%RH, and power frequency at 50/60 Hz.
- Voltage pulse output:
  Use: Time proportional output
  On-voltage: 12 V or more/load resistance of 600 Ω or more
  Off-voltage: 0.1 V DC or less
  Time resolution: 10 ms or 0.1% of output, whichever is larger

■ Step Response Time Specifications

Within 1 s (63% of analog output response time when a step change of 10 to 90% of input span is applied)

■ Relay Contact Output Specifications

- Contact type and number of outputs:
  Control output: contact point 1c; 1 point
  Heating/cooling type: contact point 1a; 2 points for both heating and cooling sides
  Alarm output: contact point 1a; 3 points (common is independent)
- Contact rating:
  Contact point 1c (control output): 250 V AC, 3 A or 30 V DC, 3A (resistance load)
  Contact point 1a (control output): 240 V AC, 3A or 30 V DC, 3A (resistance load)
  Contact point 1a (alarm output): 240 V AC, 1A or 30 V DC, 1 A (resistance load)
- Use: Time proportional output, alarm output, FAIL output, etc.
- Time resolution of control output: 10 ms or 0.1% of output, whichever is larger

Note: This cannot be used for a small load of 10 mA or less.

■ Position Proportional Output Specifications

- Position signal input:
  Slide resistance: 100 Ω to 2.5 kΩ of total resistance
  100% side and slide line: with disconnection detection
  0% side: without disconnection detection
  Current input: 4 to 20 mA (with disconnection detection)
- Sampling period: 50 ms
- Measurement resolution: 0.1% of input span
- Position proportional relay output:
  UT35A: contact point 1a; 2 points, 250 V AC, 3 A or 30 V DC, 3 A (resistance load)
  UT32A: contact point 1a; 2 points, 240 V AC, 3 A or 30 V DC, 3 A (resistance load)

Note: This cannot be used for a small load of 10 mA or less.

■ Retransmission Output Specifications

- Number of outputs: Retransmission output; 1, shared with 15 V DC loop power supply or Cooling-side control output.
- Current output: 4 to 20 mA DC or 0 to 20 mA DC/ load resistance of 600 Ω or less
- Current output accuracy: ±0.1% of span (±5% of span for 1 mA or less)
  The accuracy is that in the standard operating conditions: 23±2°C, 55±10%RH, and power frequency at 50/60 Hz.

■ 15 V DC Loop Power Supply Specifications

(Shared with retransmission output or Cooling-side control output.)

- Power supply: 14.5 to 18.0 V DC
- Maximum supply current: About 21 mA (with short-circuit current limiting circuit)

■ Contact Input Specifications

- Number of inputs: See the table of Model and Suffix Codes.
- Input type: No-voltage contact input or transistor contact input
- Input contact rating: 12 V DC, 10 mA or more
  Use a contact with a minimum on-current of 1 mA or more.
- ON/OFF detection:
  No-voltage contact input:
  Contact resistance of 1 kΩ or less is determined as "ON" and contact resistance of 50 kΩ or more as "OFF."
  Transistor contact input:
  Input voltage of 2 V or less is determined as "ON" and leakage current must not exceed 100 μA when "OFF."
- Minimum status detection hold time: Control period +50 ms
- Use: SP switch, operation mode switch, and event input

■ Transistor Contact Output Specifications

- Number of outputs: See the table of Model and Suffix Codes.
- Output type: Open collector (SINK current)
- Output contact rating: Max. 24 V DC, 50 mA
- Output time resolution: Min. 200 ms

■ Heater Break Alarm Specifications

- Number of inputs: 2
- Number of outputs: 2 (transistor contact output)
- Use: Measures the heater current using an external current transformer (CT) and generates a heater break alarm when the measured value is less than the break detection value.
- Current transformer input resistance: About 9.4 Ω
- Current transformer input range: 0.0 to 0.1 Arms (0.12 Arms or more cannot be applied.)
- Heater current setting range: OFF, 0.1 to 300.0 Arms
  Heater current measured value display range: 0.0 to 360.0 Arms
  Note: The CT ratio can be set. CT ratio setting range: 1 to 3300
- Recommended CT: CT from U.R.D., Ltd.
  CTL-6-S-H: CT ratio 800, measurable current range: 0.1 to 80.0 Arms
  CTL-12L-30: CT ratio 3000, measurable current range: 0.1 to 180.0 Arms
- Heater current measurement period: 200 ms
- Heater current measurement accuracy: ±5% of current transformer input range span ± 1digit (CT error is not included.)
- Heater current detection resolution: Within 1/250 of current transformer input range span
- Break detection On-time: Min. 0.2 second (for time proportional output)

■ 24 V DC Loop Power Supply Specifications

- Use: Power is supplied to a 2-wire transmitter.
- Power supply: 21.6 to 28.0 V DC
- Rated current: 4 to 20 mA DC
- Maximum supply current: About 30 mA (with short-circuit current limiting circuit.)

■ Safety and EMC Standards

- Safety: Compliant with IEC/EN61010-1 (CE), approved by CAN/CSA C22.2 No.61010-1 (CSA), approved by UL61010-1.
  Installation category: CAT. II Pollution degree: 2
  Measurement category: I (CAT. I)
  Rated measurement input voltage: Max. 10 V DC
  Rated transient overvoltage: 1500 V (Note)

Note: This is a reference safety standard value for Measurement Category I of IEC/EN/CSA/UL61010-1. This value is not necessarily a guarantee of instrument performance.

- EMC Conformity standards:
  CE marking
  EN61326-1 Class A, Table 2 (For use in industrial locations)
  EN61326-2-3
  EN 55011 Class A, Group1
  EN 61000-3-2 Class A
  EN 61000-3-3
  C-tick mark
  EN 55011 Class A, Group1
  The instrument continues to operate at a measurement accuracy of within ±20% of the range during testing.

■ Construction, Installation, and Wiring

- Dust-proof and drip-proof: IP56 (for front panel) (Not available for side-by-side close mounting.)
- Material: Polycarbonate (Flame retardancy: UL94V-0)
- Case color: White (Light gray) or Black (Light charcoal gray)
- Weight: 0.5 kg or less
- External dimensions (mm):
  UT35A: 96 (W) × 96 (H) × 65 (depth from the panel face)
  UT32A: 48 (W) × 96 (H) × 65 (depth from the panel face)
  (Depth except the projection on the rear panel)
- Installation: Direct panel mounting; mounting bracket, one each for upper and lower mounting
- Panel cutout dimensions (mm):
  UT35A: $92^{+0.8/0}$ (W) × $92^{+0.8/0}$ (H)
  UT32A: $45^{+0.6/0}$ (W) × $92^{+0.8/0}$ (H)
- Mounting attitude: Up to 30 degrees above the horizontal. No downward titling allowed.
- Wiring: M3 screw terminal with square washer (for signal wiring and power wiring)

■ Power Supply Specifications and Isolation

- Power supply:
  Rated voltage: 100-240 V AC (+10%/-15%), 50/60 Hz
  24 V AC/DC (+10%/-15%) (for /DC option)
- Power consumption: UT35A: 18 VA (DC:9 VA, AC: 14 VA if /DC option is specified)
  UT32A: 15 VA (DC:7 VA, AC: 11 VA if /DC option is specified)
- Data backup: Nonvolatile memory
- Power holdup time: 20 ms (for 100 V AC drive)
- Withstanding voltage
  Between primary terminals and secondary terminals: 2300 V AC for 1 minute
  Between primary terminals: 1500 V AC for 1 minute
  Between secondary terminals: 500 V AC for 1 minute
  (Primary terminals: Power* and relay output terminals; Secondary terminals: Analog I/O signal terminals, contact input terminals, communication terminals and functional grounding terminals.)
  *: Power terminals for 24V AC/DC models are the secondary terminals.
- Insulation resistance: Between power supply terminals and a grounding terminal 20 MΩ or more at 500 V DC
- Isolation specifications

PV (universal) input terminals	Internal circuits	Power supply
Control, retransmission (analog) output terminals (not isolated between the analog output terminals) Valve position (feedback) input terminals		
Control relay (contact point c/contact point a x 2) output terminals		
Alarm-1 relay (contact point a) output terminals		
Alarm-2 relay (contact point a) output terminals		
Alarm-3 relay (contact point a) output terminals		
Position proportional relay output terminals		
Contact input terminals (all) RS-485 communication terminals (2 ports)		
24 V DC loop power supply terminals		
Contact output (transistor) terminals		
Ethernet communication terminal		
PROFIBUS-DP/DeviceNet/CC-Link communication terminals		
Current transformer input terminals		

The circuits divided by lines are insulated mutually.

■ Environmental Conditions

Normal Operating Conditions:

- Ambient temperature: -10 to 50ºC (-10 to 40ºC for side-by-side close mounting)
  For the CC-Link option, 0 to 50 ºC (0 to 40 ºC for side-by-side close mounting)
- Ambient humidity: 20 to 90% RH (no condensation allowed)
- Magnetic field: 400 A/m or less
- Continuous vibration at 5 to 9 Hz: Half amplitude of 1.5 mm or less, 1oct/min for 90 minutes each in the three axis directions
  Continuous vibration at 9 to 150 Hz: 4.9 m/s^2 or less, 1oct/min for 90 minutes each in the three axis directions
- Short-period vibration: 14.7 m/s^2, 15 seconds or less
- Shock: 98 m/s^2 or less, 11 ms
- Altitude: 2000 m or less above sea level
- Warm-up time: 30 minutes or more after the power is turned on
- Startup time: Within 10 seconds
  *: The LCD (a liquid crystal display) is used for a display portion of this product. The LCD has a characteristic that the display action becomes late at the low temperature. However, the control function is not affected.

Transportation and Storage Conditions:

- Temperature: -25 to 70ºC
- Temperature change rate: 20ºC/h or less
- Humidity: 5 to 95% RH (no condensation allowed)

Effects of Operating Conditions

- Effect of ambient temperature:
  Voltage or TC input: ±1 µV/ºC or ±0.01% of F.S./ºC, whichever is larger
  Current input: ±0.01% of F.S./ºC
  RTD input: ±0.05ºC/ºC (ambient temperature) or less
  Analog output: ±0.02% of F.S./ºC or less
- Effect of power supply voltage fluctuation
  Analog input: ±0.05% of F.S. or less
  Analog output: ±0.05% of F.S. or less
  (Each within rated voltage range)

5. How to Connect Wires

WARNING

- **Wiring work must be carried out by a person with basic electrical knowledge and practical experience.**
- **Be sure to turn OFF the power supply to the controller before wiring to avoid an electric shock. Use a tester or similar device to ensure that no power is being supplied to a cable to be connected.**
- **As a safety measure, always install a circuit breaker (an IEC 60947-compatible product, 5 A, 100 V or 220 V AC) in an easily accessible location near the instrument. Moreover, provide indication that the switch is a device for turning off the power to the instrument.**
- **Install the power cable keeping a distance of more than 1 cm from other signal wires.**
- **The power cable is required to meet the IEC standards concerned or the requirements of the area in which the instrument is being installed.**
- **Wiring should be installed to conform to NEC (National Electrical Code: ANSI/NFPA-70) or the wiring construction standards in countries or regions where wiring will be installed.**
- **For control relay output, alarm relay output, and power terminal connections, use heat-resistant cables.**
- **Since the insulation provided to each relay output terminal is Functional insulation, provide Reinforced insulation to the external of the device as necessary. (Refer to the drawing below.)**



CAUTION

- **When connecting two or more crimp-on terminal lugs to the single terminal block, bend the crimp-on terminal lugs before tightening the screw.**
- **Note that the wiring of two or more crimp-on terminal lugs to the single high-voltage terminal of the power supply and relay, etc. does not comply with the safety standard.**

CAUTION

- **Provide electricity from a single-phase power supply. If the power is noisy, install an isolation transformer on the primary side, and use a line filter on the secondary side. When measures against noise are taken, do not install the primary and secondary power cables close to each other.**
- **If there is a risk of external lightning surges, use a lightning arrester etc.**
- **For TC input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires.**
- **Since the control output relay has a life span (resistance load of 100,000 times), use the auxiliary relay to perform ON/OFF control.**
- **The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.**
- **After completing the wiring, the terminal cover is recommended to use for the instrument.**

● Recommended Crimp-on Terminal Lugs



Recommended tightening torque: 0.6 N·m
Applicable wire size: Power supply wiring 1.25 mm^2 or more

Applicable terminal lug	Applicable wire size mm^2 (AWG#)	(φ d)	(A)	(F)
M3	0.25 to 1.65 (22 to 16)	3.3	5.5	4.2

● Cable Specifications and Recommended Cables

Purpose	Name and Manufacturer
Power supply, relay contact outputs	600 V Grade heat-resistant PVC insulated wires, JIS C 3317(HIV), 0.9 to 2.0 mm^2
Thermocouple	Shielded compensating lead wires, JIS C 1610
RTD	Shielded wires (three/four conductors), UL2482 (Hitachi Cable)
Other signals (other than contact input/output)	Shielded wires
Other signals (contact input/output)	Unshielded wires
RS-485 communication	Shielded wires
Ethernet communication	100 BASE-TX (CAT-5)/10 BASE-T
PROFIBUS-DP communication	Dedicated cable for PROFIBUS-DP (Shielded two-wires)
DeviceNet communication	Dedicated cable for DeviceNet (Shielded five-wires)
CC-Link communication	Dedicated cable for CC-Link (Shielded three-wires)

PROFIBUS-DP/CC-Link Connector (wiring side) (Part number: A1987JT)
DeviceNet Connector (wiring side) (Part number: L4502BW)
Recommended tightening torque: 0.5 to 0.6 N·m

DC Relay Wiring



AC Relay Wiring


UT35A/UT32A
External AC power supply
R
CR filter
(Mount it directly to the relay coil terminal (socket).)
UT's contact
(Use one with a relay coil rating less than the UT's contact rating.)
Relay

6. Terminal Wiring Diagrams

CAUTION

- **Do not use an unassigned terminal as the relay terminal.**
  Do not use a 100-240 V AC power supply for the 24 V AC/DC model; otherwise, the instrument will malfunction.

■ UT35A


Control output OUT (Suffix code: Type1=-0)
Relay contact output
NC 101
NO 102
COM 103
Contact rating: 250 V AC, 3 A
30 V DC, 3 A (resistance load)
Terminal wiring differs in Heating/cooling control and Position proportional control. Refer to the terminals of Position proportional control output and Heating/cooling control output below.
Factory default: Control output is relay.
Heating/cooling control output (Suffix code: Type 1=-2)
Heating/cooling relay contact output
OUT2 Cooling-side NO 101
OUT Heating-side NO 102
COM 103
Contact rating: 240 V AC, 3 A
30 V DC, 3 A (resistance load)
Contact output ALM (Equipped as standard)
External contact output (relay)
Alarm-3 output (PV high limit)
Common
Alarm-2 output (PV low limit)
Common
Alarm-1 output (PV high limit)
Common
AL3 104 105
AL2 106 107
AL1 108 109
UT
Relay contact rating: 240 V AC, 1 A
30 V DC, 1 A (resistance load)
Power supply
100-240 V AC power supply
N 110
L 111
112
Allowable range:
100-240 V AC (±10%)
(free voltage)
50/60 Hz shared
24 V AC/DC power supply
110
111
112
(24 V AC/DC power supply: Optional suffix code /DC)
Factory default: PV input type is undefined.
PV input PV (Equipped as standard)
TC input
RTD input
202 203
A 201 b 202 B 203
Current (mA) input
Voltage (mV, V) input
203 204
202 203
E4-terminal area
E1-terminal area
101 -112
501 -512
401 -412
301 -306
201 -212
401
Wiring direction
E3-terminal area
Position proportional control output VALV (Suffix code: Type1=-1)
Relay contact output
Feedback input
HIGH (direct) 507
LOW (reverse) 508
COM 509
100% 510
511
0% 512
Contact rating: 250 V AC, 3A
30 V DC, 3 A
(resistance load)
Resistance: 100 Ω to 2.5 kΩ
Feedback input
Current (mA) input
510
511
512
When feedback input is current
Retransmission output RET (Equipped as standard)
Retransmission output
Default: PV retransmission
4-20 mA DC or 0-20 mA DC
Load resistance 600 Ω or less
Default: 4-20 mA DC
205
206
15 V DC loop power supply
14.5-18.0 V DC (Max. 21 mA DC)
Can be used for 15 V DC loop power supply when not used for retransmission output.
Cooling-side control output RET/OUT2 (Suffix code: Type 1=-2)
Current/voltage pulse output
0-20 mA DC, 4-20 mA DC, Voltage pulse (12V)
205
206
Can not be used for retransmission output or 15 V DC loop power supply when current/voltage pulse output is used.
Can be used for retransmission output or 15 V DC loop power supply when control output is not used.
Current output range can be changed.
Control output OUT (Suffix code: Type1=-0, -1 or -2)
Current/voltage pulse output
0-20 mA DC, 4-20 mA DC, Voltage pulse (12 V)
207
208
Retransmission output
Default: Undefined
0-20 mA DC, 4-20 mA DC
Default: 4-20 mA DC
15 V DC loop power supply
14.5-18.0 V DC (Max. 21 mA DC)
Can be used for retransmission output or 15 V DC loop power supply when current/voltage pulse output is not used for control output.
Current output range can be changed.
In Position proportional type, can be used for retransmission output or 15 V DC loop power supply.
Contact input DI (Equipped as standard)
External contact input
STOP when DI2=ON
RUN when DI2=OFF
AUTO when DI1=ON
MAN when DI1=OFF
Common
No-voltage contact
Transistor contact
UT
210 DI2
211 DI1
212 COM
+5V
Contact rating: 12 V DC, 10 mA or more
Function can be assigned to the terminals with no function.
Heater break alarm HBA (Optional suffix code /HA)
External contact output (transistor)
Heater break alarm-1 output
Heater break alarm-2 output
Common
HAL1 507
HAL2 508
COM 509
UT
Heater current detection input
CT1 510
CT2 511
512
COM
Transistor contact rating: 24 V DC, 50 mA

■ UT35A (Continued from page 3)



301-306 E1-Terminal Area

Contact input **DI** (Suffix code: Type 2=2)



Contact rating: 12 V DC, 10 mA or more

Function can be assigned to the terminals with no function.

Contact input / Contact output **DI/DO** (Suffix code: Type 2=1)



Contact rating: 12 V DC, 10 mA or more



Transistor contact rating: 24 V DC, 50 mA

Function can be assigned to the terminals with no function.

501-506 E4-Terminal Area

Contact output **DO** (Suffix code: Type 2=2)



Transistor contact rating: 24 V DC, 50 mA

Function can be assigned to the terminals with no function.

24 V DC loop power supply

LPS24

(Optional suffix code /LP)



■ UT32A


Control output
OUT
(Suffix code: Type1=-0)
Relay contact output
NC
NO
COM
Contact rating: 250 V AC, 3 A
30 V DC, 3 A (resistance load)
Terminal wiring differs in Heating/cooling control and Position proportional control. Refer to the terminals of Position proportional control output and Heating/cooling control output below.
Factory default: Control output is relay.
Factory default: PV input type is undefined.
PV input
PV (Equipped as standard)
TC input
RTD input
Current (mA) input
Voltage (mV, V) input
Retransmission output
RET (Equipped as standard)
Retransmission output
15 V DC loop power supply
Default: PV retransmission
4-20 mA DC or 0-20 mA DC
Load resistance 600 Ω or less
Default: 4-20 mA DC
14.5-18.0 V DC (Max. 21 mA DC)
Can be used for 15 V DC loop power supply when not used for retransmission output.
Cooling-side control output
RET/OUT2
(Suffix code: Type 1=-2)
Current/voltage pulse output
0-20 mA DC, 4-20 mA DC, Voltage pulse (12 V)
Can not be used for retransmission output or 15 V DC loop power suppy when current/voltage pulse output is used for control output.
Can be used for retransmission output or 15 V DC loop power suppy when control output is not used.
Current output range can be changed.
Heating/cooling control output
(Suffix code: Type 1=-2)
OUT2
OUT
Heating/cooling relay contact output
Cooling-side
Heating-side
Contact rating: 240 V AC, 3 A
30 V DC, 3 A (resistance load)
E1-terminal area
101 -112
301 -312
201 -212
Wiring direction
Control output
OUT (Suffix code: Type1=-0, -1 or -2)
Default: Undefined
Default: 4-20 mA DC
Can be used for retransmission output or 15 V DC loop power suppy when current/voltage pulse output is not used for control output.
Current output range can be changed.
In Position proportional type, can be used for retransmission output or 15 V DC loop power supply.
Contact output
ALM (Equipped as standard)
External contact output (relay)
Alarm-3 output (PV high limit)
Alarm-2 output (PV low limit)
Alarm-1 output (PV high limit)
Common
AL3
AL2
AL1
Relay contact rating: 240 V AC, 1 A
30 V DC, 1 A (resistance load)
Contact input
DI (Equipped as standard)
External contact input
STOP when DI2=ON
RUN when DI2=OFF
AUTO when DI1=ON
MAN when DI1=OFF
DI2
DI1
Contact rating: 12 V DC, 10 mA or more
Function can be assigned to the terminals with no function.
Position proportional control output
VALV
(Suffix code: Type1=-1)
Relay contact output
Feedback input
HIGH (direct)
LOW (reverse)
Contact rating: 240 V AC, 3A
30 V DC, 3 A
(resistance load)
Resistance: 100 Ω to 2.5 kΩ
Current (mA) input
When feedback input is current
Heater break alarm
HBA (Optional suffix code /HA)
External contact output (transistor)
Heater break alarm-1 output
Heater break alarm-2 output
HAL1
HAL2
Heater current detection input
CT1
CT2
Transistor contact rating: 24 V DC, 50 mA
Power supply
100-240 V AC power supply
24 V AC/DC power supply
(24 V AC/DC power supply: Optional suffix code /DC)
Allowable range:
100-240 V AC (±10%)
(free voltage)
50/60 Hz shared

401-412 E3-Terminal Area

RS-485 communication **RS485**



(Suffix code: Type 3=1)

Ethernet communication (with gateway function)

10BASE-T/100BASE-TX RJ45 connector

ETHR

(Suffix code: Type 3=2)

Upper side LED (baud rate)	
Color	Amber
Lit	100M bps
Unlit	10M bps
Lower side LED (link activity)	
Color	Green
Lit	Linked
Blink	Active
Unlit	Link failure



PROFIBUS-DP communication (with Modbus master)



Pin	Signal name	Description
1	VP	+5V bus power
2	RxD/TxD-P	Data signal (positive data receive/transmit)
3	RxD/TxD-N	Data signal (negative data recive/transmit)
4	DGND	Signal ground
5	SHIELD	Shield ground

LED	Lit	Unlit
CHK (red)	User profile error	Normal
RDY (green)	Normal Communicating successfully	No power, or Communication failure
ERR (red)	Not connected, or communication failure (flashing)	Normal

PROF

(Suffix code: Type 3=4)

If the UT is located at the end of a segment for the PROFIBUS communication wiring, terminating resistors are separately needed. These are to be prepared by users. (390 Ω: 2 pcs. 220 Ω: 1 pc., or an active terminator.)



CC-Link communication (with Modbus master)



Pin	Signal name	Description
1	FG	Flame ground
2	SLD	Shield
3	DG	RX/TX signal ground
4	DB	RX/TX - signal
5	DA	RX/TX + signal

LED	Lit	Unlit
CHK (red)	User profile error/ Address error	Normal
L ERR (red)	Communication failure (CRC error)	Normal
L RUN (green)	Normal Communicating successfully	No carrier detected/ Communication timeout

CC-L

(Suffix code: Type 3=3)

If the UT is located at the end of a segment for the CC-Link communication wiring, terminating resistors are separately needed. These are to be prepared by users. (110 Ω: 1 pc.)



DeviceNet communication (with Modbus master)



Pin	Signal name	Description
1	V+	DeviceNet power supply 24V
2	CAN_H	RX/TX + signal
3	DRAIN	Shield/Drain wire
4	CAN_L	RX/TX - signal
5	V-	DeviceNet power supply common

LED	Lit/flashing	Unlit
CHK (red)	User profile error	Normal
MNS (green/ red)	Normal. Communicating successfully (green, lit). Not connected (green, flashing).	No electricity
	Critical link failure (red, lit). Communication timeout (red, flashing)	
	At power-on/Communication faulted (green/red, flashing)	

DNET

(Suffix code: Type 3=5, except Type 2=3)

If the UT is located at the end of a segment for the DeviceNet communication wiring, terminating resistors are separately needed. These are to be prepared by users. (121 Ω: 1 pc.)



301-306 E1-Terminal Area

RS-485 communication **RS485**



(Suffix code: Type 2=1)

24 V DC loop power supply



LPS24

(Suffix code: Type 2=0 and optional suffix code /LP)

Contact input / Contact output **DI/DO** (Suffix code: Type 2=2)



Contact rating: 12 V DC, 10 mA or more



Function can be assigned to the terminals with no function.

Transistor contact rating: 24 V DC, 50 mA

RS-485 communication/24 V DC loop power supply



RS485/LPS24

(Suffix code: Type 2=1 and optional suffix code /LP)

Operation Guide

UT35A/UT32A
Digital Indicating Controllers
Operation Guide

Initial Settings

YOKOGAWA
Yokogawa Electric Corporation

This operation guide describes basic settings and operations of the UT35A/UT32A.
For details of each function, see the electronic manual.
The scrolling guide is displayed on PV display in the Parameter Setting Display.
This guide can be turned on/off with the Fn key.

Contents

1. Names and Functions of Display Parts
2. Setup Procedure
3. Quick Setting Function (Setting of Input and Output)
4. Adjusting Valve Position Automatically (for a Position Proportional Type Controller Only)
5. Setting Alarm Type
6. Setting Alarm Setpoint

1. Names and Functions of Display Parts



(2) + (3) + (4) : Setpoint display

No. in figure	Name	Description
(1)	PV display (white or red)	Displays PV. Displays an error code if an error occurs. Displays the scrolling guide in the Menu Display and Parameter Setting Display when the guide display ON/OFF is set to ON.
(2)	Group display (green)	Displays a group number (1 to 4 or R) and terminal area (E1 to E4). 1 to 4 represent SP numbers in the Operation Display. R and E1 to E4 are displayed in the Parameter Setting Display.
(3)	Symbol display (orange)	Displays a parameter symbol.
(4)	Data display (orange)	Displays a parameter setpoint and menu symbol.
(5)	Bar-graph display (orange)	Displays control output value (OUT) and measured input value (PV). The data to be displayed can be set by the parameter. Initial value: Deviation, Heating-side control output (in Heating/cooling control)
(6)	Event indicator (orange)	Lit when the alarms 1 to 4 occur. Event displays other than alarms can be set by the parameter.
(7)	Key navigation indicator (green)	Lit or blinks when the Up/Down or Left/Right arrow key operation is possible.
(8)	Parameter display level indicator (green)	Displays the setting conditions of the parameter display level function.
(9)	Status indicator (green and red)	Displays the operating conditions and control status.
(10)	Security indicator (red)	Lit if a password is set. The setup parameter settings are locked.
(11)	Ladder operation indicator (green)	Lit while the ladder operation is executed.

Parameter display level	EASY	PRO
Easy setting mode	Lit	Unlit
Standard setting mode	Unlit	Unlit
Professional setting mode	Unlit	Lit

Indicator	Description
REM	Lit when in remote mode (REM).
STOP	Lit when in stop mode (STOP).
MAN	Lit when in manual mode (MAN). Blinks during auto-tuning.



No. in figure	Name	Description
(1)	UT35A: DISPLAY key UT32A: DISP key	Used to switch the Operation Displays. Press the key in the Operation Display to switch the provided Operation Displays. Press the key in the Menu Display or Parameter Setting Display to return to the Operation Display.
(2)	UT35A: PARAMETER key UT32A: PARA key	Hold down the key for 3 seconds to move to the Operation Parameter Setting Display. Hold down the key and the Left arrow key simultaneously for 3 seconds to move to the Setup Parameter Setting Display. Press the key in the Parameter Setting Display to return to the Menu Display. Press the key once to cancel the parameter setting (setpoint is blinking).
(3)	SET/ENTER key Up/Down/Left/Right arrow keys	SET/ENTER key Press the key in the Menu Display to move to the Parameter Setting Display of the Menu. Press the key in the Parameter Setting Display to transfer to the parameter setting mode (setpoint is blinking), and the parameter can be changed. Press the key during parameter setting mode to register the setpoint. Up/Down/Left/Right arrow keys Press the Left/Right arrow keys in the Menu Display to switch the Displays. Press the Up/Down/Left/Right arrow keys in the Parameter Setting Display to switch the Displays. Press the Up/Down arrow keys during parameter setting mode (setpoint is blinking) to change a setpoint. Press the Left/Right arrow keys during parameter setting mode (setpoint is blinking) to move between digits according to the parameter.
(4)	Light-loader interface	It is the communication interface for the adapter cable used when setting and storing parameters from a PC. The LL50A Parameter Setting Software (sold separately) is required.
(5)	A/M key	Used to switch between AUTO and MAN modes. The setting is switched between AUTO and MAN each time the key is pressed.
(6)	User function keys	The UT35A has F1, F2, and Fn keys. The UT32A has only the Fn key. The user can assign a function to the key. The function is set by the parameter.

Note: The communication connector (maintenance port) for LL50A Parameter Setting Software is on the top of the unit.

2. Setup Procedure

The following flowchart shows the setup procedure for UT35A/UT32A.



3. Quick Setting Function (Setting of Input and Output)

The Quick setting function is a function to easily set the basic function of the controller.
Turn on the controller to start the Quick setting function.
This function allows you to easily set the control type, input, and output, and quickly start the control action.
The items (parameters) to be set by Quick setting function are as follows.
(1) Control type (PID control, Heating/cooling control, etc.)
(2) Input function (PV input type, range, scale (at voltage input), etc.)
(3) Output function (control output type and cycle time)

After turning on the controller, first decide whether or not to use the Quick setting function.

Operation in Initial Display

- Press the SET/ENTER key while YES is displayed to start the Quick setting function.
- If you change YES to NO and press the SET/ENTER key, Operation Display will appear without starting the Quick setting function.

Operation for Setting

- To select the parameter setting displayed as the initial value, press the Down arrow key to move to the next parameter.
- To change and set the parameter setting, press the SET/ENTER key to start the setpoint blinking. The blinking state allows you to make changes (setting mode). Use the Up/Down/Left/Right arrow keys to change the setpoint. Press the SET/ENTER key to register the setting.

■ Making Settings Using Quick Setting Function

Example: Setting to PID control, thermocouple type K (range of 0.0 to 500.0°C), and current control output

For the detailed procedure and switching of displays, see "Flow of Quick Setting Function" below. For the parameters to set, see the next page.

(1) Press the SET/ENTER key while YES for QSM (Quick setting mode) is displayed.
(2) Set the control type parameter (CNT) to PID (PID control).
(3) Set the PV input type parameter (IN) to K1 (-270.0 to 1370.0 °C).
(4) Set the PV input unit parameter (UNIT) to C (Degree Celsius).
(5) Set the maximum value of PV input range parameter (RH) to 500.0.
(6) Set the minimum value of PV input range parameter (RL) to 0.0.
(7) Set the output type selection parameter (OT) to OUT terminals (current=00.02).
(8) Finally, EXIT is displayed. Change NO to YES and press the SET/ENTER key to complete the setup. Operation Display appears.

■ Flow of Quick Setting Function

In Quick setting mode, the parameter guide appears on PV display.
This guide can be turned on/off with the Fn key.

Power-on

Quick setting starts

1.

[YES] Press the SET/ENTER key while YES is displayed to start the Quick setting.

[NO] ▽Select NO with the Down arrow key and press the SET/ENTER key.

2.

First, the control type parameter (CNT) is displayed.
Initial value: PID (PID control)

▽ Press the Down arrow key.

3.

The PV input type parameter (IN) is displayed.
Initial value: OFF

Press the SET/ENTER key.

4.

OFF blinks.
Blinking allows you to change the setting.

△ Press the Up arrow key.

5.

K1 is displayed.

Press the SET/ENTER key.

6.

K1 has been registered.

▽ Press the Down arrow key.

Select NO to return to the Operation Display.

7.

The PV input unit parameter (UNIT) is displayed.
Initial value: C (Degree Celsius)

▽ Press the Down arrow key.

8.

The upper limit value of the setting range is displayed for the parameter RH (maximum value of PV input range).

Press the SET/ENTER key.

9.

The last digit of the upper limit value blinks.

△▽ ◁ ▷ Change the setpoint using the Up/Down arrow keys to increase and decrease the value and the Left/Right arrow keys to move between digits.

10.

The parameter RH (maximum value of PV input range) has been changed to 500.0.

Press the SET/ENTER key.

11.

The setpoint for the parameter RH has been registered.

▽ Press the Down arrow key.

Follow the same procedure to set RL to 0.0 and OT to 00.02.
Set other parameters as needed.

12.

Finally, EXIT is displayed.
Press the SET/ENTER key to swtich to the setting mode.
Change NO to YES and press the SET/ENTER key to complete the setup of the basic function.
Operation Display appears.
The Quick setting function continues in the NO state.

Operation Display

Displays the measured input value (PV).
Displays the target setpoint (SP).

■ Parameters to be set

Control Type

Parameter Symbol	Name of Parameter	Setting Range
CNT	Control type	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis) 2P2L: Two-position two-level control H/C: Heating/cooling control

Note: Some setpoints may not be displayed depending on the model and suffix codes.

Input Function

Parameter Symbol	Name of Parameter	Setting Range
IN	PV input type	OFF: Disable K1: -270.0 to 1370.0 °C / -450.0 to 2500.0 °F K2: -270.0 to 1000.0 °C / -450.0 to 2300.0 °F K3: -200.0 to 500.0 °C / -200.0 to 1000.0 °F J: -200.0 to 1200.0 °C / -300.0 to 2300.0 °F T1: -270.0 to 400.0 °C / -450.0 to 750.0 °F T2: 0.0 to 400.0 °C / -200.0 to 750.0 °F B: 0.0 to 1800.0 °C / 32 to 3300 °F S: 0.0 to 1700.0 °C / 32 to 3100 °F R: 0.0 to 1700.0 °C / 32 to 3100 °F N: -200.0 to 1300.0 °C / -300.0 to 2400.0 °F E: -270.0 to 1000.0 °C / -450.0 to 1800.0 °F L: -200.0 to 900.0 °C / -300.0 to 1600.0 °F U1: -200.0 to 400.0 °C / -300.0 to 750.0 °F U2: 0.0 to 400.0 °C / -200.0 to 1000.0 °F W: 0.0 to 2300.0 °C / 32 to 4200 °F PL2: 0.0 to 1390.0 °C / 32.0 to 2500.0 °F P2040: 0.0 to 1900.0 °C / 32 to 3400 °F WRE: 0.0 to 2000.0 °C / 32 to 3600 °F JPT1: -200.0 to 500.0 °C / -300.0 to 1000.0 °F JPT2: -150.00 to 150.00 °C / -200.0 to 300.0 °F PT1: -200.0 to 850.0 °C / -300.0 to 1560.0 °F PT2: -200.0 to 500.0 °C / -300.0 to 1000.0 °F PT3: -150.00 to 150.00 °C / -200.0 to 300.0 °F 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20: 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV
UNIT	PV input unit	-: No unit, C: Degree Celsius -: No unit, - -: No unit, - - -: No unit, F: Degree Fahrenheit
RH	Maximum value of PV input range	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH) - For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage / current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL = RH.)
RL	Minimum value of PV input range	
SDP	PV input scale decimal point position	0: No decimal place 3: Three decimal places 1: One decimal place 4: Four decimal places 2: Two decimal places
SH	Maximum value of PV input scale	-19999 to 30000, (SL<SH), | SH - SL | ≤ 30000
SL	Minimum value of PV input scale	

Note 1: SDP, SH, and SL are displayed only for voltage/current input.
Note 2: W: W-5%Re/W-26%Re (Hoskins Mfg.Co.), ASTM E988

Output Function

Parameter Symbol	Name of Parameter	Setting Range	
OT	Output type selection Upper two digits — Lower two digits	Control output or Heating-side control output (Lower two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current)	Cooling-side control output (Upper two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current)
CT	Control output cycle time Heating-side control output cycle time (in Heating/cooling control)	0.5 to 1000.0 s	
CTc	Cooling-side control output cycle time (in Heating/cooling control)		

4. Adjusting Valve Position Automatically (for a Position Proportional Type Controller Only)

The following operating procedure describes how to input feedback signals from the control valve and adjust the fully-open and fully-closed positions of the control valve automatically. The fully-open and fully-closed positions of the valve can be adjusted automatically by inputting feedback signals from the valve. To adjust the valve position, you need to carry out the connection and bring the controller into manual mode. For the connection, see “6. Terminal Wiring Diagrams” in "Installation and Wiring", and for the manual mode, see “5. Switching between AUTO and MAN” in "Operations."

1. Show the Operation Display.
MAN is lit

+ PARAMETER Hold down the keys for 3 seconds.
* When a password is set, PASS is displayed. If the correct password is not entered, setup parameters cannot be changed.

2. SEtUP CtL — CTL menu is displayed.
▷ Press the Right arrow key until OUT menu appears.

3. SEtUP OUt — OUT menu is displayed.
Press the SET/ENTER key.

4. VAt OFF — The parameter V.AT (automatic valve position adjustment) is displayed.
Press the SET/ENTER key.

5. VAt OFF — OFF blinks.
△ Press the Up arrow key.

6. VAt ON — ON is displayed. Blinks during the change.
Press the SET/ENTER key.

7. VAt ON — ON has been registered and the automatic adjustment of the valve position starts. V.AT blinks during the automatic adjustment. After the adjustment is completed, press the DISPLAY key or DISP key once to return to the Operation Display.

- When the adjustment is completed normally, the indication automatically returns to OFF.
- When VAT.E appears on PV display, it indicates an error. Check the wiring for feedback input and perform the automatic adjustment again. To perform a valve adjustment manually, see User’s Manual.

5. Setting Alarm Type

The following operating procedure shows an example of changing the alarm-1 type (factory default: PV high limit alarm) to PV low limit alarm (setpoint: 02).

1. Show the Operation Display.

PARAMETER Hold down the key for 3 seconds.

2. OPEn MOdE — MODE menu is displayed.
▷ Press the Right arrow key until ALRM menu appears.

3. OPEn ALRM — ALRM menu is displayed.
Press the SET/ENTER key.

4. AL 1 0000 1 — The parameter AL1 (alarm-1 type) is displayed.
Press the SET/ENTER key.

5. AL 1 0000 1 — The last digit of the setpoint blinks.
△▽ ◁▷ Change the setpoint using the Up/Down arrow keys to increase and decrease the value and the Left/Right arrow keys to move between digits.
Press the SET/ENTER key.

6. AL 1 0000 2 — The alarm-1 type setpoint 02 (PV low limit) is registered.
After the setup is completed, press the DISPLAY key or DISP key once to return to the Operation Display.

Symbol
Stand-by action
Energized/De-energized
Latch action

- To change the alarm type, change the last 2 digits of the 5-digit value.
- Stand-by action and excitation are turned on or off by selecting 1 or 0. (See “Setting Display of Alarm Type.”)
- For the latch action, see User’s Manual.

Alarm Type (Alarm Setpoint)	Alarm Action (Energized)	Alarm Action (De-energized)
No alarm (00)	-	-
PV high limit (01) Analog input PV high limit (19)	Hysteresis; Open (unlit) / Closed (lit); PV; Alarm setpoint	Hysteresis; Closed (unlit) / Open (lit); PV; Alarm setpoint
PV low limit (02) Analog input PV low limit (20)	Hysteresis; Closed (lit) / Open (unlit); Alarm setpoint; PV	Hysteresis; Open (lit) / Closed (unlit); Alarm setpoint; PV
SP high limit (03) Target SP high limit (09)	Hysteresis; Open (unlit) / Closed (lit); SP or Target SP; Alarm setpoint	Hysteresis; Closed (unlit) / Open (lit); SP or Target SP; Alarm setpoint
SP low limit (04) Target SP low limit (10)	Hysteresis; Closed (lit) / Open (unlit); Alarm setpoint; SP or Target SP	Hysteresis; Open (lit) / Closed (unlit); Alarm setpoint; SP or Target SP
Deviation high limit (05) Target SP deviation high limit (11)	Hysteresis; Open (unlit) / Closed (lit); PV; Deviation setpoint; SP or Target SP; ⊕	Hysteresis; Closed (unlit) / Open (lit); PV; Deviation setpoint; SP or Target SP; ⊕
Deviation low limit (06) Target SP deviation low limit (12)	Hysteresis; Closed (lit) / Open (unlit); Deviation setpoint; PV; ⊖ SP or Target SP	Hysteresis; Open (lit) / Closed (unlit); Deviation setpoint; PV; ⊖ SP or Target SP
Deviation high and low limits (07) Target SP deviation high and low limits (13)	Hysteresis Hysteresis; Closed (lit) / Open (unlit) / Closed (lit); Deviation setpoint; PV; SP or Target SP	Hysteresis Hysteresis; Open (lit) / Closed (unlit) / Open (lit); Deviation setpoint; PV; SP or Target SP
Deviation within high and low limits (08) Target SP deviation within high and low limits (14)	Hysteresis Hysteresis; Open (unlit) / Closed (lit) / Open (unlit); Deviation setpoint; PV; SP or Target SP	Hysteresis Hysteresis; Closed (unlit) / Open (lit) / Closed (unlit); Deviation setpoint; PV; SP or Target SP
Control output high limit (15) Cooling-side control output high limit (17)	Hysteresis; Open (unlit) / Closed (lit); Output; Alarm setpoint	Hysteresis; Closed (unlit) / Open (lit); Output; Alarm setpoint
Control output low limit (16) Cooling-side control output low limit (18)	Hysteresis; Closed (lit) / Open (unlit); Alarm setpoint; Output	Hysteresis; Open (lit) / Closed (unlit); Alarm setpoint; Output

Feedback input high limit (27)	Fault diagnosis alarm (30) Burnout of PV input, ADC failure, RJC error.
Feedback input low limit (28)	
PV velocity (29)	FAIL (31) For the factory default, the contact output is turned ON in normal operation, OFF at the time of FAIL. Control output: OFF or 0%, Alarm output: OFF

Note 1: “Open/closed” shows status of relay contact, and “lit/unlit” shows status of EV (event) lamp.
Note 2: ⊕ Positive setpoint, ⊖ Negative setpoint

Setting Display of Alarm Type



Stand-by Action


°C
Treated as normal
Normal
Abnormal
The alarm output turns on.
PV low limit alarm setpoint
The alarm output does not turn on in this region even if the PV value is below PV low limit alarm setpoint.
Power-on
Time

6. Setting Alarm Setpoint

The following operating procedure shows an example of setting the alarm-1 setpoint of group 1 to 180.0.
Before setting the alarm setpoint, check the alarm type.
To change the alarm type, see “5. Setting Alarm Type.”

1. Show the Operation Display.

2. Display MODE menu with the same procedure as described in Setting Alarm Type.
▷ Press the Right arrow key.

3. OPEn SP — SP menu is displayed.
Press the SET/ENTER key.
▽ Press the Down arrow key until A1 appears.

4. A 1 150.0 — The parameter A1 is displayed. A1 to A4 represent the alarm-1 to -4 setpoints.
Group

Each parameter and group can be changed in the Parameter Setting Displays of alarms using arrow keys.
△▽ Up/Down arrow keys: parameters
◁▷ Left/Right arrow keys: groups

Display the parameter and group that need to be changed.
Press the SET/ENTER key.

5. A 1 150.0 — Blinks during the change.
△▽ ◁▷ Change the setpoint using the Up/Down arrow keys to increase and decrease the value and the Left/Right arrow keys to move between digits.
Press the SET/ENTER key.

6. A 1 180.0 — The setpoint has been registered. After the setup is completed, press the DISPLAY key or DISP key once to return to the Operation Display.

Operation Guide

UT35A/UT32A
Digital Indicating Controllers
Operation Guide

Operations

YOKOGAWA
Yokogawa Electric Corporation

This operation guide describes key entries for operating the UT35A/UT32A.
Although the display of UT35A is used in this guide, UT32A can be operated similarly.
For operations using external contact inputs, see "DI" of "6. Terminal Wiring Diagrams" in "Installation and Wiring."
If you cannot remember how to carry out an operation during setting, press the DISPLAY key or DISP key once. This brings you to the display (Operation Display) that appears at power-on.
The scrolling guide is displayed on PV display in the Parameter Setting Display.
This guide can be turned on/off with the Fn key.

Contents

1. Monitoring-purpose Operation Displays Available during Operation
2. Setting Target Setpoint (SP)
3. Performing/Canceling Auto-tuning
4. Selecting Target Setpoint Numbers (SPNO.)
5. Switching between AUTO and MAN
6. Switching between RUN and STOP
7. Switching between REM (Remote) and LCL (Local)
8. Manipulating Control Output in Manual Mode
9. Troubleshooting

1. Monitoring-purpose Operation Displays Available during Operation

■ Operation Display Switching Diagram for Standard and Position Proportional Types

- **SP Display**
  Displays the measured input value on PV display.
  Displays the target setpoint (SP) on Setpoint display (SP can be changed).
- **OUT Display**
  Displays the measured input value on PV display.
  Displays the control output value (OUT) on Setpoint display (OUT can be changed in manual mode).
  Displays the valve's feedback input value (at 0 to 100% valve opening) in Position proportional control.



■ Operation Display Switching Diagram for Heating/Cooling Type

- **SP Display**
  Displays the measured input value on PV display.
  Displays the target setpoint (SP) on Setpoint display (SP can be changed).
- **OUT Display**
  Displays the measured input value on PV display.
  Displays the control output values (C.H.) of heating and cooling sides on Setpoint display (C.H. can be changed in manual mode).



After showing the OUT Display, press the DISPLAY key or DISP key to show the following displays conditionally.
For details, see User's Manual.

Standard, Position Proportional, and Heating/Cooling Types

- SELECT Displays 1 to 5 (which appear when registered)
- Analog Input Display (display only) (factory default: non-display)
- Position Proportional Computation Output Display (display only) (factory default: non-display)
- PID Number Display (display only) (factory default: non-display)
- Heater Break Alarm-1 Current Display (display only) (for heater break alarm option only)
- Heater Break Alarm-2 Current Display (display only) (for heater break alarm option only)

2. Setting Target Setpoint (SP)



1. Show the SP Display (Operation Display).
(This is an example of setting the target setpoint to 150.0).

2. Press the SET/ENTER key to start the last digit of the setpoint blinking.
Blinking allows you to change the value.

3. ◁▷ To set the setpoint, use the
△▽ Left/Right arrow keys to move between digits and the Up/Down arrow keys to increase and decrease the value.

4. When the required value is displayed, press the SET/ENTER key to register the setpoint.

3. Performing/Canceling Auto-tuning

Auto-tuning should be performed after setting a target setpoint.
Make sure that the controller is in automatic mode (AUTO) and in run mode (RUN) before auto-tuning. For setting to AUTO, see "5. Switching between AUTO and MAN," and for setting to RUN, see "6. Switching between RUN and STOP."
If the setpoint is known in advance or auto-tuning does not find any appropriate PID constants, set the PID manually. For setting the PID manually, see User's Manual.

CAUTION

Do not perform auto-tuning for the following processes.
Tune PID manually.
- **Processes with fast response such as flow rate control and pressure control.**
- **Processes which do not allow the output to be turned on and off even temporarily.**
- **Processes which prohibit severe output changes at control valves (or other actuators).**
- **Processes in which product quality can be adversely affected if PV values fluctuate beyond their allowable ranges.**

1. Show the Operation Display.

2.

PARAMETER
Hold down the PARAMETER key or PARA key for 3 seconds to display MODE menu.

Press the SET/ENTER key.

3.

In cases where the communication is specified, the parameter R.L (REMOTE/LOCAL switch) is displayed.

▽ Press the Down arrow key until the parameter AT appears.

4.

The parameter AT (auto-tuning switch) is displayed.

Press the SET/ENTER key.

5.

OFF blinks.

△▽ Press the Up/Down arrow keys to display the required setpoint.

6.

Blinks during the change.

The setting range is 1 to 4 (represent group numbers) or R.
To perform auto-tuning for the PID of group 1, set the parameter AT to 1.
To quit the auto-tuning, set the parameter to OFF.

Press the SET/ENTER key.

7.

The setpoint has been registered.
This starts auto-tuning.
The limiter can be set to the output during auto-tuning.
For details, see User's Manual.

During auto-tuning,
- The MAN lamp blinks.
- The OUT symbol appears.
- The output values at 100.0% and 0% appear alternately.

8.

The MAN lamp goes off, which means that the auto-tuning completed normally.

4. Selecting Target Setpoint Numbers (SPNO.)

The following operating procedure shows an example of changing the target setpoint number (SPNO.) from 1 to 2. Each SP has its PID group. The PID group set for the parameter PIDN (PID number selection) is used.

1. Show the Operation Display.

2.

PARAMETER
Hold down the PARAMETER key or PARA key for 3 seconds to display MODE menu.

Press the SET/ENTER key.

3.

In cases where the communication is specified, the parameter R.L (REMOTE/LOCAL switch) is displayed.

▽ Press the Down arrow key until the parameter SPNO. appears.

4.

The parameter SPNO. (SP number selection) is displayed.

Press the SET/ENTER key.

5.

△▽ Change the setpoint using the Up/Down arrow keys.

Blinks during the change.

Press the SET/ENTER key.

6.

The setpoint has been registered.
Press the DISPLAY key or DISP key once to return to the Operation Display.

7.

SPNO. has been changed to 2.

5. Switching between AUTO and MAN

AUTO and MAN switching can be performed using any of the following: (1) A/M key, (2) Contact input, (3) Communication, and (4) User function key.
The figure below shows a direct operation using the A/M key.
When AUTO and MAN switching function is assigned to the contact input, and the contact input is ON, the switching by key operation cannot be performed.
For details, see User's Manual.



When AUTO is switched into MAN, the control output value in AUTO mode is held.
The controller can be operated manually from the hold value.
If the manual preset output is set (MPON parameter ≠ OFF), the controller can be operated manually from the arbitrary output value (MPO1 to MPO5 parameters).

6. Switching between RUN and STOP

RUN and STOP switching can be performed using any of the following: (1) Contact input, (2) Parameter, (3) Communication, and (4) User function key.
The following shows an example of switching using the contact input.
(The switching function is assigned to DI2 contact for the factory default.)
For details of other switching methods and the display appearing when the operation is started, see User's Manual.
When the controller is stopped, input and outputs are as follows:

PV input	Displays the PV value.
Control output	Displays the preset output value. The preset output value is set for each PID group.
Alarm output	Turns the output on in case of an alarm.

Display in STOP mode

"STOP" is displayed on Symbol display and "preset output value" is displayed on Data display.



Display in STOP mode in Heating/cooling control

"Cooling-side preset output value" is displayed on the left side of the "ST" symbol, and "Heating-side preset output value" is on the right side.



7. Switching between REM (Remote) and LCL (Local)

Remote and local switching can be performed using any of the following:
(1) Contact input, (2) Parameter, (3) Communication, and (4) User function key.

LCL (Local)

Control is performed using the target setpoint set on the controller.

REM (Remote)

Control is performed using a setpoint via communication for the target setpoint. The following shows an example of switching from local to remote using the parameter. (Only in cases where the communication is specified.)
For details of other switching methods, see User's Manual.

• The PID group for the local SP number is used as PID in remote mode.

NOTE

When the contact input is ON, operation cannot be performed using the parameter, communication, or key. When the contact input is OFF and the setting is switched using the parameter, communication, or key, the last switching operation is performed.

1. Show the Operation Display.

2.



PARAMETER

Hold down the PARAMETER key or PARA key for 3 seconds to display MODE menu.

Press the SET/ENTER key.

3.

The parameter R.L (REMOTE/LOCAL switch) is displayed.

Press the SET/ENTER key.

4.

△▽Change the operation mode using the Up/Down arrow keys. Blinks during the change.

Press the SET/ENTER key.

5.

The REM lamp is lit.

8. Manipulating Control Output in Manual Mode

NOTE

In manual mode, control output is manipulated by operating the keys (the value is changed using the Up/Down arrow keys, then outputted as it is).
Even if the SET/ENTER key is not pressed, the control output value changes according to the displayed value.
In stop mode (when the STOP lamp is lit), control output cannot be manipulated.



MAN lamp is lit.

Up arrow key: increases control output.
Down arrow key: decreases control output.

In Position proportional control:
Up arrow key; opens the valve.
Down arrow key; closes the valve.
Output; only while pressing a key.
OUT; valve opening (0-100%)

Output manipulation in Position proportional control is not restricted from output limiters (OH, OL).

Manual operation in Heating/cooling control



Up arrow key: concurrently decreases cooling-side control output and increases heating-side control output.
Down arrow key: concurrently increases cooling-side control output and decreases heating-side control output.
(Either none of the heating-side and cooling-side outputs are presented, or both of them are presented according to the dead band setting.)



9. Troubleshooting

■ Troubleshooting Flow

If the Operation Display does not appear after turning on the controller's power, check the procedures in the following flowchart.
If a problem appears to be complicated, contact our sales representatives.



* The LCD (a liquid crystal display) is used for a display portion of this product. The LCD has a characteristic that the display action becomes late at the low temperature. Additionally, the luminance and contrast degradation are caused due to aged deterioration. However, the control function is not affected.

■ Remedies if Power Failure Occurs during Operations

- Instantaneous power failure within 20 ms.
  A power failure is not detected. Normal operation continues.
- Power failure for less than about 5 seconds, or for about 5 seconds or more.
  Affects the "settings" and "operation status."
  For details, see User's Manual.

NOTE

Write down the settings of parameters for a repair request.

■ Errors at Power On

The errors shown below may occur in the fault diagnosis when the power is turned on. (For details of Setpoint display and input/output action when each error occurs, see User's Manual.

PV display (Operation Display)	Setpoint display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
Indication off	Indication off	—	—	Faulty MCU RAM / MCU ROM	MCU RAM / MCU ROM are failed.	Faulty. Contact us for repair.
ERR	SYS - - - - -	—	—	System data error	System data is corrupted.	Faulty. Contact us for repair.
	PAR 0004 (for user default value error only)		Setup parameter (PA.ER)	User (parameter) default value error	User parameter is corrupted. Initialized to factory default value.	Check and reconfigure the initialized setting parameters. Error indication is erased when the power is turned on again.
	PAR 0010 (for setup parameter error only)			Setup parameter error	Setup parameter data is corrupted. Initialized to user default value.	
	PAR 0020 (for operation parameter error only)			Operation parameter error	Operation parameter data is corrupted. Initialized to user default value.	
	SLOT 0015 (0015: Error occurs to all hardware of E1 to E4-terminal areas.)		Setup parameter (OP.ER)	Nonresponding hardware of extended function (E1 to E4-terminal areas)	Inconsistence of system data and hardware of extended function. Nonresponding communication between hardware of extended function (E1 to E4-terminal areas).	Faulty. Contact us for repair.
Normal indication	Normal indication	Rightmost decimal point on PV display blinks.	Setup parameter (PA.ER)	Calibration value error	Initialized to calibrated default value because of corrupted factory default value.	Faulty. Contact us for repair.
		Rightmost decimal point on Symbol display blinks.		Faulty FRAM	Data writing (storing) to FRAM is impossible.	
Normal indication	Normal indication	LADDER lamp blinks	Setup parameter (LA.ER)	Corrupted ladder program	Ladder program is corrupted. Operates without ladder program.	Download the ladder program again.
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	—	Setup parameter (OP.ER)	User profile error	User profile is corrupted.	Download the user profile again.

■ Errors during Operation

The errors shown below may occur during operation. (For input/output action when each error occurs, see User's Manual.

PV display (Operation Display)	Setpoint display (Operation Display)	Status indicator (Operation Display)	Parameter that displays error details	Error description	Cause and diagnosis	Remedy
AD.ERR	Normal indication (Note)	—	Setup parameter (AD1.E)	Analog input terminal ADC error •PV input	Analog input terminal AD value error	Faulty. Contact us for repair.
RJC.E (Displays RJC. E and PV alternately.)	Normal indication (Note)	—	Setup parameter (AD1.E)	Universal input terminal RJC error •PV input	Universal input terminal RJC error	Faulty. Contact us for repair. Set the parameter RJC to OFF to erase error indication.
B.OUT	Normal indication (Note)	—	Setup parameter (AD1.E)	Analog input terminal burnout error •PV input	Analog input terminal sensor burnout	Check wiring and sensor. Error indication is erased in normal operation.
			Setup parameter (PV1.E)	PV input burnout error	Burnout of analog input connected to PV	Check wiring and sensor of connected analog input terminals. Error indication is erased in normal operation.
OVER -OVER	Normal indication	—	Setup parameter (PV1.E)	PV input over-scale PV input under-scale (PV values out of -5 to 105%)	PV input is out of -5 to 105%. Also occurs when the data out of range which is the ladder calculation result is input.	Check analog input value or ladder program.
Normal indication	OUT - - - - -	—	Setup parameter (AD2.E)	Feedback input resistor/current burnout	Feedback input burnout	Check wiring of feedback input resistor/current. Error indication is erased in normal operation.
Normal indication	Normal indication	LADDER lamp blinks	Setup parameter (LA.ER)	Ladder calculation overflow	Floating point computation for ladder calculation is infinite.	Check the ladder program.
				Load factor over 100%	Computation does not end within the control period (load factor is 100% or more).	Change the control period or reduce the number of steps for the ladder program.
				Load factor over 200% (Forced end)	Computation does not end within the control period (load factor is 200% or more).	Change the control period or reduce the number of steps for the ladder program.
				Ladder program error	Ladder program is corrupted.	Download the ladder program again. If the error indication is still not erased, there is a fault. Contact us for repair.
	0.000 00000 (Decimal point on the left of the Symbol display blinks)	—	Setup parameter (OP.ER)	Peer-to-peer communication error	Peer-to-peer communication error	Check that the target devices are connected correctly. Recovery at normal receipt.
AT.E	Normal indication	—	Setup parameter (PV1.E)	Auto-tuning time-out	Auto-tuning does not end even when 24 hours have elapsed after the start of tuning.	Check the process. Hold down any key to erase the error indication
VAT.E	Normal indication	—	Setup parameter (AD2.E)	Valve position automatic adjustment error	Fully-closed valve position is equal to or larger than the fully-open valve position after automatic valve position adjustment is performed.	Check wiring and valve. Hold down any key to erase the error indication.
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	—	Setup parameter (OP.ER)	Communication error (RS-485 communication)	Framing parity error Buffer overflow Inter-character time-out Checksum error (PC link communication with checksum) CRC check error (Modbus/RTU) LRC check error (Modbus/ASCII)	Check the communication parameters. Recovery at normal receipt. Hold down any key to stop blinking.
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	—	Setup parameter (OP.ER)	Communication error (coordinated operation)	Inconsistence of loop between coordinated master and slaves	Check the communication parameters. Recovery at normal receipt. Change from remote to local mode to stop blinking.
					Communication from coordinated master is interrupted for 2 seconds.	When the mode is changed from remote to local, SP tracking does not work even if it is set to ON.
Normal indication	0.000 00000 (Decimal point on the left of the Symbol display blinks)	—	Setup parameter (OP.ER)	User profile error	User profile is corrupted.	Download the user profile again.
Normal indication	Normal indication	Rightmost decimal point on Symbol display blinks.	Setup parameter (PA.ER)	Faulty FRAM	Writing (storing) data to FRAM is impossible.	Faulty. Contact us for repair.
Undefined	Undefined	—	—	Faulty MCU / DCU (ROM / RAM error, corrupted)	MCU / DCU is corrupted.	Faulty. Contact us for repair.

Note: When an error occurs in input shown in Analog input display (Operation display), Setpoint display shows the same symbol as the PV display.

Operation Guide

UT35A/UT32A
Digital Indicating Controllers
Operation Guide

Parameters

YOKOGAWA
Yokogawa Electric Corporation

This operation guide describes the functions of parameters briefly. The parameter symbols listed are in the order shown on the display in each group of menu symbols. In addition, each parameter table has a “User Setting” column, where you can record your setpoints when setting them in the controller. The scrolling guide is displayed on PV display in the Parameter Setting Display. This guide can be turned on/off with the Fn key.

Operation Parameters

Hold down the PARAMETER key or PARA key for 3 seconds to move from the Operation Display to the Operation Parameter Setting Display. Press the DISPLAY key or DISP key once to return to the Operation Display.



The parameter groups can be switched using ◁, ▷ keys.

Move to the Setup Parameter Setting Display:
Hold down the PARAMETER key or PARA key and the Left arrow key simultaneously for 3 sec.

Operation for Setting

- To select the parameter setting displayed as the initial value, press the Down arrow key to move to the next parameter.
- To change and set the parameter setting, press the SET/ENTER key to start the setpoint blinking. The blinking state allows you to make changes (setting mode). Use the Up/Down/Left/Right arrow keys to change the setpoint. Press the SET/ENTER key to register the setting.

Note that there are some parameters which are not displayed depending on the model and suffix codes, control type (CNT), etc. The parameters for professional setting mode (LEVL: PRO) are not described in this manual. See User’s Manual.

■ Operation Mode

Menu symbol: MODE (MODE)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
SR (S.R)	STOP/RUN switch	STOP: Stop mode RUN: Run mode Preset output (PO) is generated in STOP mode. Default: Not displayed. STOP/RUN switch is assigned to contact input.	RUN		EASY
RL (R.L)	REMOTE/LOCAL switch	LCL: Local mode REM: Remote mode (Displayed only in cases where the communication is specified.)	LCL		
AT (AT)	AUTO-tuning switch	OFF: Disable 1 to 4: Perform auto-tuning. Tuning result is stored in the specified numbered PID. R: Tuning result is stored in the PID for reference deviation.	OFF		
SPNO (SPNO.)	SP number selection	1 to 4 (Depends on the setup parameter SPGR. setting.)	1		
PID (PID)	PID number	The PID group number being selected is displayed. 1 to 4, R: PID group for reference deviation	1		

■ SELECT Parameter

Menu symbol: CS (CS)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
Registered parameter symbol	SELECT parameter 10 to 19	Setting range of a registered parameter. For details, see User's Manual.	—	Table below	EASY

Parameter	n=10	n=11	n=12	n=13	n=14	n=15	n=16	n=17	n=18	n=19
CSn										

For the registration of SELECT parameters, see User's Manual.

■ SP and Alarm Setpoint Setting Parameter

Menu symbol: SP (SP)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
SP (SP)	Target setpoint	0.0 to 100.0% of PV input range (EU) (Setting range: SPL to SPH)	SPL	Table below	EASY
SUB (SUB)	Sub-target setpoint (in Two-position two-level control)	Set the offset from SP. -100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span		
PIDN (PIDN)	PID number selection	Set a PID group number to use. 1 to 4 (Depends on the setup parameter PIDG. setting.)	1 to 4		
A1 to A4 (A1 to A4)	Alarm-1 to -4 setpoint	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, output alarm, or velocity alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type	0		

For the parameter SP (target setpoint), 4 groups are displayed for the factory default. The number of groups can be changed by the setup parameter SPGR. (number of SP groups). For the alarm setpoint parameter, alarm-1 to -4 are displayed for the factory default. The number of alarms can be changed using the setup parameter ALNO. (number of alarms). To change the number of SP groups or alarms, see User's Manual.

Use the following table to record SP and alarm setpoints.

Parameter	n=1	n=2	n=3	n=4
SP				
SUB				
PIDN				
A1				
A2				
A3				
A4				

n: group number

■ SP-related Setting Parameter

Menu symbol: SPS (SPS)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
RT (RT)	Remote input ratio	SP = Remote input x RT + Remote input bias 0.001 to 9.999	1.000		STD
RBS (RBS)	Remote input bias	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span		
UPR (UPR)	SP ramp-up rate	Used to prevent SP from changing suddenly. Set a ramp-up rate or ramp-down rate per hour or minute. Set a time unit using the parameter TMU. OFF, 0.0 + 1 digit to 100.0% of PV input range span (EUS)	OFF		EASY
DNR (DNR)	SP ramp-down rate		OFF		
TMU (TMU)	SP ramp-rate time unit	HOUR: Ramp-up rate or ramp-down rate per hour MIN: Ramp-up rate or ramp-down rate per minute	HOUR		
SPT (SPT)	SP tracking selection	Tracking is performed when the mode changes from Remote to Local. (The local setpoint keeps track of the remote setpoint.) OFF, ON	ON		STD
PVT (PVT)	PV tracking selection	Causes the setpoint to keep track of the PV so the setpoint automatically reverts to its original value at a preset rate of change. The UPR, DNR, and TMU are used in combination. Operating conditions: 1) MAN → AUTO, 2) STOP → AUTO, 3) Power-on, 4) SP number change, 5) SP change OFF, ON	OFF		

■ Alarm Function Setting Parameter

Menu symbol: ALRM (ALRM)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
AL1 to AL4 (AL1 to AL4)	Alarm-1 to 4 type Example: Alarm-1 AL 1 00001 Latch action Energized/ De-energize Stand-by action Alarm type	Set a 5-digit value in the following order. [Alarm type: 2 digits (see below)] + [Without (0) or With (1) Stand-by action] + [Energized (0) or De-energized (1)] + [Latch action (0/1/2/3/4)] For latch action, see User's Manual. Alarm type: 2 digits 00: Disable 01: PV high limit 02: PV low limit 03: SP high limit 04: SP low limit 05: Deviation high limit 06: Deviation low limit 07: Deviation high and low limits 08: Deviation within high and low limits 09: Target SP high limit 10: Target SP low limit 11: Target SP deviation high limit 12: Target SP deviation low limit 13: Target SP deviation high and low limits 14: Target SP deviation within high and low limits 15: OUT high limit 16: OUT low limit 17: Cooling-side OUT high limit 18: Cooling-side OUT low limit 19: Analog input PV high limit 20: Analog input PV low limit 27: Feedback input high limit 28: Feedback input low limit 29: PV velocity 30: Fault diagnosis 31: FAIL	AL1, AL3: PV high limit (01) Without Stand-by action (0) Energized (0) Latch action (0) AL2, AL4: PV low limit (02) Without Stand-by action (0) Energized (0) Latch action (0)	Table below	EASY
VT1 to VT4 (VT1 to VT4)	PV velocity alarm time setpoint 1 to 4	0.01 to 99.59 (minute.second)	1.00		
HY1 to HY4 (HY1 to HY4)	Alarm-1 to -4 hysteresis	Set a display value of setpoint of hysteresis. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type. When the decimal point position for the input type is set to "1", the initial value of the hysteresis is "1.0".	10		
DYN1 to DYN4 (DYN1 to DYN4)	Alarm-1 to -4 On-delay timer	An alarm output is ON when the delay timer expires after the alarm setpoint is reached. 0.00 to 99.59 (minute.second)	0.00		STD
AMD (AMD)	Alarm mode	0: Always active 1: Not active in STOP mode 2: Not active in STOP or MAN mode	0		

For the alarm function setting parameter, 4 alarms are displayed for the factory default. The number of alarms can be changed by the setup parameter ALNO. (number of alarms). To change the number of alarms, see User's Manual.

Parameter	n=1	n=2	n=3	n=4
ALn				
VTn				
HYn				
DYNn				

n: alarm number

■ PV-related Setting Parameter

Menu symbol: PVS (PVS)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
BS (BS)	PV input bias	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span		EASY
FL (FL)	PV input filter	OFF, 1 to 120 s	OFF		

■ PID Setting Parameter

Menu symbol: PID (PID)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
P (P)	Proportional band Heating-side proportional band (in Heating/cooling control)	0.0 to 999.9% When 0.0% is set, it operates as 0.1%. Heating-side ON/OFF control applies when 0.0% in Heating/cooling control	5.0%		EASY
I (I)	Integral time Heating-side integral time (in Heating/cooling control)	OFF: Disable 1 to 6000 s	240 s		
D (D)	Derivative time Heating-side derivative time (in Heating/cooling control)	OFF: Disable 1 to 6000 s	60 s		
OH (OH)	Control output high limit Heating-side control output high limit (in Heating/cooling control)	-4.9 to 105.0%, (OL<OH) In Heating/cooling control: 0.1 to 105.0% (OL<OH)	100.0%		
OL (OL)	Control output low limit Heating-side control output low limit (in Heating/cooling control)	-5.0 to 104.9%, (OL<OH), SD: Tight shut In Heating/cooling control: 0.0 to 104.9% (OL<OH)	0.0%		
MR (MR)	Manual reset	Enabled when integral time is OFF. The manual reset value equals the output value when PV = SP. -5.0 to 105.0%	50.0%		
HYS (HYS)	Hysteresis (in ON/OFF control, Position proportional control, or Two-position two-level control) Heating-side ON/OFF control hysteresis (in Heating/cooling control)	In ON/OFF control or Two-position two-level control: 0.0 to 100.0% of PV input range span (EUS) In Heating/cooling control or Position proportional control: 0.0 to 100.0%	In ON/OFF control or Two-position two-level control: 0.5 % of PV input range span In Heating/cooling control or Position proportional control: 0.5 %		
SUHY (SU.HY)	Sub-hysteresis (in Two-position two-level control)	0.0 to 100.0% of PV input range span (EUS)	0.5 % of PV input range span		
HYUP (HY.UP)	Upper-side hysteresis (in ON/OFF control)		0.5 % of PV input range span		
HYLO (HY.LO)	Lower-side hysteresis (in ON/OFF control)		0.5 % of PV input range span		
DR (DR)	Direct/reverse action switch	RVS: Reverse action DIR: Direct action	RVS		STD
SUDR (SU.DR)	Sub-direct/reverse action switch (in Two-position two-level control)		DIR		
Pc (Pc)	Cooling-side proportional band	0.0 to 999.9% (Cooling-side ON/OFF control applies when 0.0% in Heating/cooling control)	5.0%		EASY
Ic (Ic)	Cooling-side integral time	OFF: Disable 1 to 6000 s	240 s		
dc (Dc)	Cooling-side derivative time	OFF: Disable 1 to 6000 s	60 s		
OHc (OHc)	Cooling-side control output high limit	0.1 to 105.0%, (OLc<OHc)	100.0%		
OLc (OLc)	Cooling-side control output low limit	0.0 to 104.9%, (OLc<OHc)	0.0%		
HYSc (HYSc)	Cooling-side ON/OFF control hysteresis	0.0 to 100.0%	0.5%		
db (DB)	Output dead band (in Heating/cooling control or Position proportional control)	In Heating/cooling control: -100.0 to 50.0% In Position proportional control: 1.0 to 10.0%	3.0%		
PO (PO)	Preset output Heating-side preset output (in Heating/cooling control)	In STOP mode, fixed control output can be generated. In Position proportional control, Valve opening can be set; -5.0 to 105.0%	0.0%		
SUPO (SU.PO)	Sub-preset output (in Two-position two-level control)	In STOP mode, fixed sub-control output can be generated. 0%, 100%	0%		
POc (POc)	Cooling-side preset output	In STOP mode, cooling-side fixed control output can be generated. -5.0 to 105.0%	0.0%		

For the PID setting parameter, 4 groups are displayed for the factory default.
The number of groups can be changed by the setup parameter PIDG. (number of PID groups). To change the number of PID groups, see User's Manual.

If you are using two or more groups of PID parameters, use the following table to record their setting values.

Parameter	n=2	n=3	n=4	R
P				
I				
D				
OH				
OL				
MR				
HYS				
SU.HY				
HY.UP				
HY.LO				
DR				
SU.DR				
Pc				
Ic				
Dc				
OHc				
OLc				
HYSc				
DB				
PO				
SU.PO				
POc				

n: group number

■ Tuning Parameter

Menu symbol: TUNE (TUNE)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
SC (SC)	Super function	OFF: Disable 1: Overshoot suppressing function (normal mode) 2: Hunting suppressing function (stable mode) Enables to answer the wider characteristic changes compared with response mode. 3: Hunting suppressing function (response mode) Enables quick follow-up and short converging time of PV for the changed SP. 4: Overshoot suppressing function (strong suppressing mode) Note: Setpoints 2 and 3 must be used in PID control or PI control. Disabled in the following controls: 1) ON/OFF control, 2) PD control, 3) P control, 4) Heating/cooling control. Do not use the function for the control processes with response such as flow or pressure control.	OFF		EASY
ATTY (AT.TY)	Auto-tuning type	0: Normal 1: Stability	0		STD
AR (AR)	Anti-reset windup (excess integration prevention)	AUTO, 50.0 to 200.0%	AUTO		
OPR (OPR)	Output velocity limiter	OFF: Disable 0.1 to 100.0%/s	OFF		
MPON (MPON)	Manual preset output number selection	Select the output used in MAN mode when switched from AUTO to MAN mode. OFF: Hold the control output in AUTO mode (bumpless) 1: Use manual preset output 1 (output bump) 2: Use manual preset output 2 (output bump) 3: Use manual preset output 3 (output bump) 4: Use manual preset output 4 (output bump) 5: Use manual preset output 5 (output bump)	OFF		
MPO1 to MPO5 (MPO1 to MPO5)	Manual preset output 1 to 5	-5.0 to 105.0% However, output is limited to the output high limit and low limit.	0.0%	Table below	

Use the following table to record the manual preset output setting value.

Parameter	n=1	n=2	n=3	n=4	n=5
MPOn					

■ Zone Control Parameter

Menu symbol: ZONE (ZONE)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
RP1 to RP3 (RP1 to RP3)	Reference point 1 to 3	Set reference points at which switching is carried out between groups of PID constants according to the given temperature zone. 0.0 to 100.0% of PV input range (EU) (RP1 ≤ RP2 ≤ RP3)	100.0% of PV input range	Table below	STD
RHY (RHY)	Zone PID switching hysteresis	Hysteresis can be set for switching at a reference point. 0.0 to 10.0% of PV input range span (EUS)	0.5 % of PV input range span		
RdV (RDV)	Reference deviation	Set a deviation from SP. The PID for reference deviation is used if there is a larger deviation than the preset reference deviation. OFF: Disable 0.0 + 1 digit to 100.0% of PV input range span (EUS)	OFF		

For Zone control, set the setup parameter ZON (zone PID selection) to Zone PID selection.

Use the following table to record the reference point setting value.

Parameter	n=1	n=2	n=3
RPn			

■ P Parameter (for Ladder Program)

Menu symbol: PPAR (PPAR)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
P01 to P10 (P01 to P10)	P01 to P10 parameter	-19999 to 30000 (Set a decimal point position using LL50A Parameter Setting Software.)	0	Table below	STD

Parameter	n=01	n=02	n=03	n=04	n=05	n=06	n=07	n=08	n=09	n=10
Pn										

Setup Parameters

Hold down the PARAMETER key or PARA key and Left arrow key simultaneously for 3 seconds to move from the Operation Display or Operation Parameter Setting Display to the Setup Parameter Setting Display.
Press the DISPLAY key or DISP key once to return to the Operation Display.



Move to the Operation Parameter Setting Display:
Hold down the PARAMETER key or PARA key for 3 sec.

Operation for Setting

- To select the parameter setting displayed as the initial value, press the Down arrow key to move to the next parameter.
- To change and set the parameter setting, press the SET/ENTER key to start the set-point blinking. The blinking state allows you to make changes (setting mode). Use the Up/Down/Left/Right arrow keys to change the setpoint. Press the SET/ENTER key to register the setting.

Note that there are some parameters which are not displayed depending on the Model and Suffix codes, control type (CNT), etc. The parameters for professional setting mode (LEVL: PRO) are not described in this manual. See User's Manual.

■ Control Function Setting Parameter

Menu symbol: CTL (CTL)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
CNT (CNT)	Control type	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis) 2P2L: Two-position two-level control H/C: Heating/cooling control	PID or H/C (for Heating/ Cooling type)		EASY
SPGR. (SPGR.)	Number of SP groups	Set a number of SP groups to use. 1 to 4	4		STD
ZON (ZON)	Zone PID selection	If set to "SP group number selection," allows PID constants to be selected for each SP group. If set to "Zone PID selection," automatically selects PID constants according to the range set in the Reference point. 0: SP group number selection 1 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 3: SP group number selection 2 4: Zone PID selection (selection by SP)	0		
PIDG. (PIDG.)	Number of PID groups	Set a number of PID groups to use. 1 to 4	4		

■ PV Input Setting Parameter

Menu symbol: PV (PV)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
IN (IN)	PV input type	OFF: Disable K1: -270.0 to 1370.0 °C / -450.0 to 2500.0 °F K2: -270.0 to 1000.0 °C / -450.0 to 2300.0 °F K3: -200.0 to 500.0 °C / -200.0 to 1000.0 °F J: -200.0 to 1200.0 °C / -300.0 to 2300.0 °F T1: -270.0 to 400.0 °C / -450.0 to 750.0 °F T2: 0.0 to 400.0 °C / -200.0 to 750.0 °F B: 0.0 to 1800.0 °C / 32 to 3300 °F S: 0.0 to 1700.0 °C / 32 to 3100 °F R: 0.0 to 1700.0 °C / 32 to 3100 °F N: -200.0 to 1300.0 °C / -300.0 to 2400.0 °F E: -270.0 to 1000.0 °C / -450.0 to 1800.0 °F L: -200.0 to 900.0 °C / -300.0 to 1600.0 °F U1: -200.0 to 400.0 °C / -300.0 to 750.0 °F U2: 0.0 to 400.0 °C / -200.0 to 1000.0 °F W: 0.0 to 2300.0 °C / 32 to 4200 °F PL2: 0.0 to 1390.0 °C / 32.0 to 2500.0 °F P2040: 0.0 to 1900.0 °C / 32 to 3400 °F WRE: 0.0 to 2000.0 °C / 32 to 3600 °F JPT1: -200.0 to 500.0 °C / -300.0 to 1000.0 °F JPT2: -150.0 to 150.0 °C / -200.0 to 300.0 °F PT1: -200.0 to 850.0 °C / -300.0 to 1560.0 °F PT2: -200.0 to 500.0 °C / -300.0 to 1000.0 °F PT3: -150.00 to 150.00 °C / -200.0 to 300.0 °F 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20 : 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV	OFF		EASY
UNIT (UNIT)	PV input unit	-: No unit, C: Degree Celsius -: No unit, - -: No unit, - - -: No unit, F: Degree Fahrenheit	C		
RH (RH)	Maximum value of PV input range	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH) - For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage/ current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL = RH.)	Depends on the input type		
RL (RL)	Minimum value of PV input range		Depends on the input type		
SDP (SDP)	PV input scale decimal point position	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	Depends on the input type		
SH (SH)	Maximum value of PV input scale	-19999 to 30000, (SL<SH), | SH - SL | ≤ 30000	Depends on the input type		
SL (SL)	Minimum value of PV input scale		Depends on the input type		
BSL (BSL)	PV input burnout action	OFF: Disable UP: Upscale DOWN: Downscale	Depends on the input type		STD
ABS (A.BS)	PV analog input bias	-100.0 to 100.0% of each input range span (EUS)	0.0 % of PV input range span		
AFL (A.FL)	PV analog input filter	OFF, 1 to 120 s	OFF		

W: W-5% Re/W-26% Re(Hoskins Mfg.Co.). ASTM E988, WRE: W97Re3-W75Re25

■ Input Range, SP Limiter Setting Parameter

Menu symbol: MPV (MPV)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
PUNI (P.UNI)	Control PV input unit	-: No unit C: Degree Celsius -: No unit - -: No unit - - -: No unit F: Degree Fahrenheit	Same as PV input unit		STD
PdP (P.DP)	Control PV input decimal point position	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	1		
PRH (P.RH)	Maximum value of control PV input range	-19999 to 30000, (P.RL<P.RH), | P.RH - P.RL | ≤ 30000	Depends on the input type		
PRL (P.RL)	Minimum value of control PV input range		Depends on the input type		
SPH (SPH)	SP high limit	0.0 to 100.0% of PV input range (EU), (SPL<SPH)	100.0 % of PV input range		
SPL (SPL)	SP low limit		0.0 % of PV input range		

■ Output Setting Parameter

Menu symbol: OUt (OUT)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
Ot (OT)	Output type selection 	Control output or Heating-side control output (Lower two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current) Cooling-side control output (Upper two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current)	Standard type: 00.03 Heating/cooling type: 06.03		STD
Ct (CT)	Control output cycle time Heating-side control output cycle time (in Heating/cooling control)	0.5 to 1000.0 s	30.0 s		EASY
Ctc (CTc)	Cooling-side control output cycle time		30.0 s		
V.AT (V.AT)	Automatic valve position adjustment	OFF: Stop automatic adjustment ON: Start automatic adjustment	OFF		
V.RS (V.RS)	Valve position setting reset	Setting V.RS to ON resets the valve adjustment settings and causes the indication “V.RS” to blink.	OFF		
V.L (V.L)	Fully-closed valve position setting	Pressing the SET/ENTER key with valve position set to the fully-closed position by Down arrow key causes the adjusted value to be stored. When V.L adjustment is complete, V.L stops blinking.	-		
V.H (V.H)	Fully-opened valve position setting	Pressing the SET/ENTER key with valve position set to the fully-opened position by Up arrow key causes the adjusted value to be stored. When V.H adjustment is complete, V.H stops blinking	-		
tRt (TR.T)	Valve traveling time	5 to 300 s	60 s		STD
V.MOd (V.MOD)	Valve adjusting mode	0: Valve position feedback type 1: Valve position feedback type (moves to the estimating type if a feedback input error or break occurs.) 2: Valve position estimating type	0		

rtS (RTS)	Retransmission output type of RET	OFF: Disable PV1: PV SP1: SP OUT1: OUT (Valve opening: 0 to 100 % in Position proportional control) LPS: 15 V DC loop power supply TSP1: Target SP HOUT1: Heating-side OUT COUT1: Cooling-side OUT MV1: Position proportional output (internal computed value) PV: PV terminals analog input	PV1		EASY
rtH (RTH)	Maximum value of retransmission output scale of RET	When RTS = PV1, SP1, TSP1, PV RTL + 1 digit to 30000 -19999 to RTH - 1 digit Decimal point position: When RTS=PV1, SP1, or TSP1, decimal point position is same as that of PV input. When RTS=PV, decimal point position is same as that of PV input scale.	100 % of PV input range		STD
rtL (RTL)	Minimum value of retransmission output scale of RET		0 % of PV input range		
O1rS (O1RS)	Retransmission output type of OUT current output	Same as RTS	0FF		
O1rH (O1RH)	Maximum value of retransmission output scale of OUT current output	When O1RS = PV1, SP1, TSP1, PV, O1RL + 1 digit to 30000 -19999 to O1RH - 1 digit Decimal point position: When O1RS=PV1, SP1, or TSP1, decimal point position is same as that of PV input. When O1RS =PV, decimal point position is same as that of PV input scale.	-		
O1rL (O1RL)	Minimum value of retransmission output scale of OUT current output		-		
OUtA (OU.A)	OUT current output range	4-20: 4 to 20 mA 0-20: 0 to 20 mA 20-4: 20 to 4 mA 20-0: 20 to 0 mA	4-20		
rEtA (RET.A)	RET current output range		4-20		

■ Heater Break Alarm Setting Parameter

Menu symbol: HbA (HBA)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
Hb1S (HB1.S)	Heater break alarm-1 function selection	0: Heater current measurement 1: Heater break alarm (Heating-side) 2: Cooling-side heater break alarm	1		EASY
Hb2S (HB2.S)	Heater break alarm-2 function selection		1		
Hb1 (HB1)	Heater break alarm-1 current setpoint	OFF, 0.1 to 300.0 Arms	OFF		
Hb2 (HB2)	Heater break alarm-2 current setpoint		OFF		
Ct1t (CT1.T)	CT1 coil winding number ratio	1 to 3300	800		
Ct2t (CT2.T)	CT2 coil winding number ratio		800		

HdN1 (HDN1)	Heater break alarm-1 On-delay timer	0.00 to 99.59 (m.s)	0.00		STD
HdN2 (HDN2)	Heater break alarm-2 On-delay timer		0.00		

In cases where the current transformers manufactured by U.R.D. Co., Ltd are used, set the following value for the coil winding number ratio.
CTL-6-S-H: 800
CTL-12L-30: 3000

■ RS-485 Communication Setting Parameter (UT35A: E3-terminal Area, UT32A: E1-terminal Area)

Menu symbol: R485 (R485)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
PSL (PSL)	Protocol selection	PCL: PC link communication PCLSM: PC link communication (with checksum) LADR: Ladder communication CO-M: Coordinated master station CO-S: Coordinated slave station MBASC: Modbus (ASCII) MBRTU: Modbus (RTU) CO-S1: Coordinated slave station (Loop-1 mode) CO-S2: Coordinated slave station (Loop-2 mode) P-P: Peer-to-peer communication	MBRTU		EASY
bPS (BPS)	Baud rate	600: 600 bps 1200: 1200 bps 2400: 2400 bps 4800: 4800 bps 9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	19200		
PRI (PRI)	Parity	NONE: None EVEN: Even ODD: Odd	EVEN		
StP (STP)	Stop bit	1: 1 bit, 2: 2 bits	1		
dLN (DLN)	Data length	7: 7 bits, 8: 8 bits	8		
AdR (ADR)	Address	1 to 99	1		

■ Ethernet Communication Setting Parameter (E3-terminal Area)

Menu symbol: EtHR (ETHR)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
HSR (HSR)	High-speed response mode	OFF, 1 to 8	1		EASY
bPS (BPS)	Baud rate	9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400		
PRI (PRI)	Parity	NONE: None EVEN: Even ODD: Odd	EVEN		
IP1 to IP4 (IP1 to IP4)	IP address 1 to 4	0 to 255 Initial value: (IP1).(IP2).(IP3).(IP4) = (192).(168).(1).(1)	See left	Table below	
SM1 to SM4 (SM1 to SM4)	Subnet mask 1 to 4	0 to 255 Initial value: (SM1).(SM2).(SM3).(SM4) = (255).(255).(255).(0)	See left	Table below	
dG1 to dG4 (DG1 to DG4)	Default gateway 1 to 4	0 to 255 Initial value: (DG1).(DG2).(DG3).(DG4) = (0).(0).(0).(0)	See left	Table below	
PRt (PRT)	Port number	502, 1024 to 65535	502		
IPAR (IPAR)	IP access restriction	OFF: Disable, ON: Enable	OFF		
1IP1 to 1IP4, 2IP1 to 2IP4 (1.IP1 to 1.IP4, 2.IP1 to 2.IP4)	Permitted IP address 1-1 to 1-4 Permitted IP address 2-1 to 2-4	0 to 255 Initial value: (1.IP1).(1.IP2).(1.IP3).(1.IP4) = (255).(255).(255).(255) (2.IP1).(2.IP2).(2.IP3).(2.IP4) = (255).(255).(255).(255)	See left	Table below	
ESW (ESW)	Ethernet setting switch	Setting this parameter to “ON” enables the Ethernet communication parameter settings. OFF, ON	OFF		

Use the following table to record Ethernet communication setting value.

Parameter	n=1	n=2	n=3	n=4
IPn				
SMn				
DGn				
1.IPn				
2.IPn				

■ PROFIBUS-DP Communication Setting Parameter (E3-terminal Area)

Menu symbol: PROF (PROF)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
bR (BR)	Baud rate	9.6K: 9.6k bps 19.2K: 19.2k bps 93.75K: 93.75k bps 187.5K: 187.5k bps 0.5M: 0.5M bps 1.5M: 1.5M bps 3M: 3M bps 6M: 6M bps 12M: 12M bps AUTO 45.45K: 45.45k bps	AUTO		EASY
AdR (ADR)	Address	0 to 125	3		
bPS (BPS)	Baud rate	9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400		
FILE (FILE)	Profile number	0 to 3	0		

■ DeviceNet Communication Setting Parameter (E3-terminal Area)

Menu symbol: dNEt (DNET)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
bR (BR)	Baud rate	125K: 125k bps 250K: 250k bps 500K: 500k bps	125K		EASY
AdR (ADR)	Address	0 to 63	63		
bPS (BPS)	Baud rate	9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400		
FILE (FILE)	Profile number	0 to 3	0		

■ CC-Link Communication Setting Parameter (E3-terminal Area)

Menu symbol: CC-L (CC-L)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
bR (BR)	Baud rate	156K: 156k bps 625K: 625k bps 2.5K: 2.5k bps 5M: 5M bps 10M: 10M bps	10M		EASY
AdR (ADR)	Address	1 to 64	1		
bPS (BPS)	Baud rate	9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400		
FILE (FILE)	Profile number	0 to 3	0		

■ Key Action Setting Parameter

Menu symbol: KEY (KEY)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
F1 (F1)	User function key-1 action setting	OFF: Disable A/M: AUTO/MAN switch R/L1: REM/LCL switch S/R: STOP/RUN switch AUTO: Switch to AUTO MAN: Switch to MAN REM1: Switch to REM LCL1: Switch to LCL STOP: Switch to STOP RUN: Switch to RUN AT: Auto-tuning LTUP: LCD brightness UP LTDN: LCD brightness DOWN BRI: Adjust LCD brightness LCD: LCD backlight ON/OFF switch LAT: Latch release PID: PID tuning switch	OFF		EASY
F2 (F2)	User function key-2 action setting		OFF		
Fn (Fn)	User function key-n action setting		PID		

■ Display Function Setting Parameter

Menu symbol: dI SP (DISP)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
PCMd (PCMD)	Active color PV display switch	0: Fixed in white 1: Fixed in red 2: Link to alarm 1 (Alarm OFF: white, Alarm ON: red) 3: Link to alarm 1 (Alarm OFF: red, Alarm ON: white) 4: Link to alarm 1 or 2 (Alarm OFF: white, Alarm ON: red) 5: Link to alarm 1 or 2 (Alarm OFF: red, Alarm ON: white) 6: PV limit (Within range: white, Out of range: red) 7: PV limit (Within range: red, Out of range: white) 8: SP deviation (Within deviation: white, Out of deviation: red) 9: SP deviation (Within deviation: red, Out of deviation: white) 10: Link to DI (ON: red, OFF: white)	0		EASY
PCH (PCH)	PV color change high limit	Set a display value when in PV limit or SP deviation. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	0		
PCL (PCL)	PV color change low limit		0		
bAR 1 (BAR1)	Bar-graph display registration	0: Disable 1: OUT, Heating-side OUT, Internal value in Position proportional control 2: Cooling-side OUT 3: PV 4: SP 5: Deviation 6 to 16: Disable 17: Feedback input (valve opening) 18: PV terminals analog input	5 (Heating /cooling type: 1)		STD
bdV (BDV)	Bar-graph deviation display band	0.0 to 100.0% of PV input range span (EUS)	10.0 % of PV input range span		
GUId (GUID)	Guide display ON/OFF	OFF: Nondisplay, ON: Display	ON		
ECO (ECO)	Economy mode	OFF: Disable 1: Economy mode ON (All indications except PV display OFF) 2: Economy mode ON (All indications OFF) 3: Brightness 10 % (whole indication)	OFF		
bRI (BRI)	Brightness	(Dark) 1 to 5 (Bright)	3		EASY
MLSd (MLSD)	Least significant digital mask of PV display	OFF: With least significant digit ON: Without least significant digit	OFF		STD

■ SELECT Display Setting Parameter

Menu symbol: CSEL (CSEL)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
CS 1 to CS5 (CS1 to CS5)	SELECT Display-1 to -5 registration	Register the operation parameter (except the Operation Mode) that is frequently modified to display it in the Operation Display. OFF, 2301 to 5000 For the setting range, see User's Manual.	OFF		STD

Use the following table to record SELECT Display setting value.

Parameter	n=1	n=2	n=3	n=4	n=5
CSn					

■ Key Lock Setting Parameter

Menu symbol: KLOC (KLOC)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
COMW (COM.W)	Communication write enable/disable	OFF: Enable, ON: Disable	OFF		STD
dAtA (DATA)	Front panel parameter data (▼,▲) key lock	OFF: Unlock, ON: Lock	OFF		
A/M (A/M)	Front panel A/M key lock		OFF		

■ DI Function Registration Parameter

Menu symbol: dI SL (DI.SL)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
A/M (A/M)	AUTO/MAN switch	Set an I relay number of contact input. Set "OFF" to disable the function. Standard terminals DI1: 5025, DI2: 5026 E1-terminal area DI11: 5041, DI12: 5042, DI13: 5043, DI14: 5044, DI15: 5045	5025		STD
R/L (R/L)	REMOTE/LOCAL switch		OFF		
S/R (S/R)	STOP/RUN switch		5026		
AUtO (AUTO)	Switch to AUTO		OFF		
MAN (MAN)	Switch to MAN		OFF		
REM (REM)	Switch to REMOTE		OFF		
LCL (LCL)	Switch to LOCAL		OFF		
At (AT)	Auto-tuning START/STOP switch		OFF		
LAt (LAT)	Latch release		OFF		
LCd (LCD)	LCD backlight ON/OFF switch		OFF		
PVRW (PVRW)	PV red/white switch		OFF		

■ DI Function Numbering Parameter

Menu symbol: dI NU (DI.NU)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
SPb0 (SP.B0)	Bit-0 of SP number	Set an I relay number of contact input. Set "OFF" to disable the function. Standard terminals DI1: 5025, DI2: 5026 E1-terminal area DI11: 5041, DI12: 5042, DI13: 5043, DI14: 5044, DI15: 5045	OFF		EASY
SPb 1 (SP.B1)	Bit-1 of SP number		OFF		
SPb2 (SP.B2)	Bit-2 of SP number		OFF		
PNb0 (PN.B0)	Bit-0 of PID number		OFF		STD
PNb 1 (PN.B1)	Bit-1 of PID number		OFF		
PNb2 (PN.B2)	Bit-2 of PID number		OFF		
MPb0 (MP.B0)	Bit-0 of manual preset output number		OFF		
MPb 1 (MP.B1)	Bit-1 of manual preset output number		OFF		
MPb2 (MP.B2)	Bit-2 of manual preset output number		OFF		
SPbC (SP.BC)	Bit changing method of SP number	0: Status switch 1 1: Status switch 2	0		STD

■ AL1-AL3 Function Registration Parameter

Menu symbol: ALM (ALM)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
AL 1S (AL1.S)	AL1 function selection	Set an I relay number. For the items other than below, see User's Manual. Ex.) Set the number 4353 for AL1.S to use the alarm 1. Set "OFF" to disable the function. No function: OFF Alarm 1: 4353 Alarm 2: 4354 Alarm 3: 4355 Alarm 4: 4357 AUTO (ON) / MAN (OFF) status: 4193 REM (ON) / LCL (OFF) status: 4194 STOP (ON) / RUN (OFF) status: 4195 FAIL (Normally ON) output: 4256	4353		STD
AL2S (AL2.S)	AL2 function selection		4354		
AL3S (AL3.S)	AL3 function selection		4355		
ORS (OR.S)	OUT relay function selection		OFF		
OR2S (OR2.S)	OUT2 relay function selection		OFF		

■ DO Setting Parameter (E1/E4-terminal Area)

Menu symbol: dO (DO)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
dO 1S (DO1.S)	DO11/DO41 function selection	Same as AL1.S Set "OFF" to disable the function	OFF	Table below	STD
dO2S (DO2.S)	DO12/DO42 function selection		OFF		
dO3S (DO3.S)	DO43 function selection		OFF		
dO4S (DO4.S)	DO44 function selection		OFF		
dO5S (DO5.S)	DO45 function selection		OFF		

Use the following table to record DO setting value.

Parameter	E1-terminal Area	E4-terminal Area
DO1.S		
DO2.S		
DO3.S		
DO4.S		
DO5.S		

■ System Setting Parameter

Menu symbol: SYS (SYS)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
RMd (R.MD)	Restart mode	Set how the controller should recover from a power failure of 5 seconds or more. CONT: Continue action set before power failure. MAN: Start from MAN. AUTO: Start from AUTO.	CONT		STD
RtM (R.TM)	Restart timer	Set time between power on and the instant where controller starts computation. 0 to 10 s	0		
EPO (EPO)	Input error preset output	Set preset output value when the input burnout or ADC error occurs. Manual output is prioritized when the input burnout occurs in MAN. 0: Preset output 1: 0% output 2: 100% output	0		
FREQ (FREQ)	Power frequency	AUTO, 60: 60 Hz, 50: 50 Hz	AUTO		EASY
QSM (QSM)	Quick setting mode	OFF: Disable ON: Enable	ON		
LANG (LANG)	Guide display language	ENG: English FRA: French GER: German SPA: Spanish	Depends on the model and suffix codes		
PASS (PASS)	Password setting	0 (No password) to 65535	0		

■ Error and Version Confirmation Parameter (for display only)

Menu symbol: VER (VER)

Parameter symbol	Name of Parameter	Status record	Display level
PAER (PA.ER)	Parameter error status		EASY
OPER (OP.ER)	Option error status		
Ad 1E (AD1.E)	A/D converter error status 1		
Ad2E (AD2.E)	A/D converter error status 2		
PV 1E (PV1.E)	PV input error status		
LAER (LA.ER)	Ladder error status		
MCU (MCU)	MCU version		
dCU (DCU)	DCU version		
ECU 1 (ECU1)	ECU-1 version (E1-terminal area)		
ECU3 (ECU3)	ECU-3 version (E3-terminal area)		
ECU4 (ECU4)	ECU-4 version (E4-terminal area)		
PARA (PARA)	Parameter version		
HVER (H.VER)	Product version		
SER 1 (SER1)	Serial number 1		
SER2 (SER2)	Serial number 2		
MAC 1 (MAC1)	MAC address 1 (E3-terminal area)		
MAC2 (MAC2)	MAC address 2 (E3-terminal area)		
MAC3 (MAC3)	MAC address 3 (E3-terminal area)		

■ Parameter Display Level Parameter

Menu symbol: LVL (LVL)

Parameter symbol	Name of Parameter	Setting Range	Initial value	User setting	Display level
LEVL (LEVL)	Parameter display level	EASY: Easy setting mode STD: Standard setting mode PRO: Professional setting mode	STD		EASY

* For Professional setting mode, see User's Manual.

Trademarks
- Our product names or brand names mentioned in this manual are the trademarks or registered trademarks of Yokogawa Electric Corporation.
- Adobe, Acrobat, and Postscript are either registered trademarks or trademarks of Adobe Systems Incorporated.
- Ethernet is a registered trademark of XEROX Corporation in the United States.
- Modbus is a registered trademark of Schneider Electric.
- PROFIBUS-DP is a registered trademark of PROFIBUS User Organization.
- DeviceNet is a registered trademark of Open DeviceNet Vendor Association.
- CC-Link is a registered trademark of CC-Link Partner Association.
- We do not use the TM or ® mark to indicate these trademarks or registered trademarks in this manual.
- All other product names mentioned in this manual are trademarks or registered trademarks of their respective companies.